



# AMD 800 Series

Motherboard

## Software/BIOS Setup Guide

Version 1.0

Published July 2024

Copyright©2024 ASRock INC. All rights reserved.

Version 1.0

Published July 2024

Copyright©2024 ASRock INC. All rights reserved.

## Copyright Notice:

No part of this documentation may be reproduced, transcribed, transmitted, or translated in any language, in any form or by any means, except duplication of documentation by the purchaser for backup purpose, without written consent of ASRock Inc.

Products and corporate names appearing in this documentation may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

## Disclaimer:

Specifications and information contained in this documentation are furnished for informational use only and subject to change without notice, and should not be constructed as a commitment by ASRock. ASRock assumes no responsibility for any errors or omissions that may appear in this documentation.

To the extent permitted by law, with respect to the contents of this documentation, ASRock does not provide warranty of any kind, either expressed or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose.

In no event shall ASRock, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock has been advised of the possibility of such damages arising from any defect or error in the documentation or product.

## Contact Information:

If you need to contact ASRock or want to know more about ASRock, you're welcome to visit ASRock's website at <http://www.asrock.com>; or you may contact your dealer for further information. For technical questions, please submit a support request form at <https://event.asrock.com/tsd.asp>

### **ASRock Incorporation**

e-mail: [info@asrock.com.tw](mailto:info@asrock.com.tw)

### **ASRock EUROPE B.V.**

e-mail: [sales@asrock.nl](mailto:sales@asrock.nl)

### **ASRock America, Inc.**

e-mail: [sales@asrockamerica.com](mailto:sales@asrockamerica.com)

# Contents

<b>Chapter 1 Introduction</b>	<b>1</b>
<b>Chapter 2 Software and Utilities Operation</b>	<b>2</b>
2.1 Auto Driver Installer (ADI)	2
2.1.1 Installing Drivers for the First Time	2
2.1.2 Updating Drivers	6
2.2 ASRock Live Update & APP Shop	7
2.2.1 Installing ASRock Live Update & APP Shop	7
2.2.2 UI Overview	8
2.2.3 Apps	9
2.2.4 BIOS & Drivers	12
2.2.5 Setting	13
2.3 ASRock Motherboard Utility (A-Tuning)	14
2.3.1 Installing ASRock Motherboard Utility (A-Tuning)	14
2.3.2 Using ASRock Motherboard Utility (A-Tuning)	14
2.4 Phantom Gaming Tuning	17
2.4.1 Installing Phantom Gaming Tuning	17
2.4.2 Using Phantom Gaming Tuning	17
2.5 ASRock Polychrome SYNC	20
2.5.1 Connecting the LED Strip	20
2.5.2 Connecting the Addressable RGB LED Strip	21
2.5.3 Installing ASRock Polychrome SYNC Utility	22
2.6 Nahimic Audio	23

<b>Chapter 3 UEFI SETUP UTILITY</b>	<b>25</b>
3.1 Introduction	25
3.1.1 Entering BIOS Setup	25
3.1.2 EZ Mode	26
3.1.3 Advanced Mode	27
3.1.4 UEFI Menu Bar	27
3.1.5 Navigation Keys	28
3.2 Main Screen	29
3.3 OC Tweaker Screen	30
3.4 Advanced Screen	37
3.4.1 CPU Configuration	39
3.4.2 PCI Configuration	40
3.4.3 Onboard Devices Configuration	41
3.4.4 Storage Configuration	43
3.4.5 ACPI Configuration	44
3.4.6 USB Configuration	46
3.4.7 Trusted Computing	47
3.4.8 AMD CBS	49
3.4.9 AMD PBS	65
3.4.10 AMD Overclocking	69
3.5 Tool	70
3.6 Hardware Health Event Monitoring Screen	72
3.7 Security Screen	77
3.8 Boot Screen	81
3.9 Exit Screen	83

# Chapter 1 Introduction

This user guide is a complete setup guide for all AMD 800-series motherboards. The screenshots in this manual are for reference only. Settings and options may vary due to the motherboard you purchased.

In this documentation, Chapter 1 gives an overview of the setup guide. Chapter 2 contains the operation guide of the software and utilities. Chapter 3 contains the configuration guide of the BIOS setup.

## Software Setup Guide

- Auto Driver Installer (ADI)
- ASRock Live Update & APP Shop
- ASRock Motherboard Utility (A-Tuning)
- Phantom Gaming Tuning
- ASRock Polychrome SYNC
- Nahimic Audio

## BIOS Setup Guide

- UEFI Setup Utility



*Because the motherboard specifications and the software might be updated, the content of this documentation will be subject to change without notice. In case any modifications of this documentation occur, the updated version will be available on ASRock's website without further notice. If you require technical support related to this motherboard, please visit our website for specific information about the model you are using. ASRock website <http://www.asrock.com>.*

# Chapter 2 Software and Utilities Operation

## 2.1 Auto Driver Installer (ADI)


Optical drive or driver DVD is no longer needed for driver installation. ASRock motherboard already has its Ethernet driver prepacked in BIOS ROM. When you finish installing the operation system, simply use the Auto Driver Installer to download and install all necessary drivers automatically.

### 2.1.1 Installing Drivers for the First Time

Follow the instructions to install all necessary drivers via the Auto Driver Installer. Please note that the Internet access is required during the following procedures.

#### **Step 1**

After you install the Windows OS, connect your computer to the Internet.



## Step 2

Boot into the system, and a notification will pop up in the lower right corner of your screen saying, "**Do you want to one-step-install the latest drivers simply from ASRock Auto Driver Installer?**".

Select "Yes" to install Auto Driver Installer.

Select "No" to skip the installation.



1. The Auto Driver Installer will automatically pop up for users to install drivers only when the "Auto Driver Installer" item under the "Tool" menu in the BIOS is set to [Enabled]. The item is enabled by default; therefore, for the first-time users, there is no need to change the setting in the BIOS.
2. An available Internet connection is a prerequisite for using the Auto Driver Installer. If you boot into the system without Internet, the Auto Driver Installer won't appear. Now connect your computer to the Internet, wait a few seconds, and then the Auto Driver Installer will pop up.
3. If you select "No" in Step 2 and skip the installation, the Auto Driver Installer will be removed. If you would like to run the application again, please enable the "Auto Driver Installer" item in the BIOS setting.

## Step 3

When it's completed, you will see the Auto Driver Installer icon on your desktop and then the Auto Driver Installer appears.




#### Step 4

The Auto Driver Installer panel lists all available drivers that your motherboard supports. Select one or more drivers to be installed.

Click "Select All" to select all items.

Click "Unselect All" to remove all of your selections.

Click "Update" to start downloading and installing drivers.



*If there are no drivers to be installed, click "Finish" to exit. If you would like to run the application again, please enable the "Auto Driver Installer" item in the BIOS setting.*



**Step 5**

A message pops up saying, "During installation, your system may reboot and continue installing remaining item(s)".


Click "Yes" to continue.

Click "No" to exit.

**Step 6**

Once all drivers are successfully installed, a message pops up saying, "Installation has been successfully completed! For further drivers and utilities, please visit ASRock's website."

Click "Ok" to complete the procedure.




When driver installation is completed, the Auto Driver Installer tool will be uninstalled automatically from your computer.



*After driver installation, the Auto Driver Installer will be removed. If you would like to run the application again, please go to the "Tool" menu in the BIOS setting, and set the "Auto Driver Installer" item to [Enabled].*

## 2.1.2 Updating Drivers

Updating drivers ensures that your system work well without any issue. To update drivers, please go to ASRock' website (<https://www.asrock.com>) and select "Support" > "Latest Drivers Update".




## 2.2 ASRock Live Update & APP Shop

The ASRock Live Update & APP Shop is an online store for purchasing and downloading software applications for your ASRock computer. You can quickly and easily install various apps and support utilities. With ASRock Live Update & APP Shop, you can optimize your system and keep your motherboard up to date simply with a few clicks.


### 2.2.1 Installing ASRock Live Update & APP Shop

Please download the ASRock Live Update & APP Shop utility from the ASRock's website: "https://www.asrock.com".

Go to the product page of your motherboard, select "Support" > "Download" to download the APP Shop.




Description	OS	Size	Date	Download
Realtek high definition audio driver ver.9231.1_LIAD_WHQL_Nahimic	Windows® 11 64bit	35.5MB	2021/10/12	<a href="#">Global</a> <a href="#">China</a>
AMD chipset driver ver.3.10.22.706	Windows® 11 64bit	50.33MB	2021/11/30	<a href="#">Global</a> <a href="#">China</a>
Killer Lan driver ver.3.0.1606	Windows® 11 64bit	38.8MB	2021/10/8	<a href="#">Global</a> <a href="#">China</a>
AMD RAIDXpert2 Utility ver.9.2.0.158	Windows® 11 64bit	95.4MB	2021/5/31	<a href="#">Global</a> <a href="#">China</a>
SATA Floppy Image_CC ver:9.3.0.296	Windows® 11 64bit	361KB	2022/2/8	<a href="#">Global</a> <a href="#">China</a>
SATA Floppy Image_DID ver:9.3.0.296	Windows® 11 64bit	361KB	2022/2/8	<a href="#">Global</a> <a href="#">China</a>
<b>NVMe_DID Supported AMD processors:</b> (Ryzen) - AMD Ryzen™ 5000 Series Desktop Processors with Radeon™ Graphics (Renai) - AMD Ryzen™ 4000 Series Desktop Processors with Radeon™ Graphics (Cezanne) - AMD Ryzen™ 5000 Series Desktop Processors with Radeon™ Graphics	Windows® 11 64bit	361KB	2022/2/8	<a href="#">Global</a> <a href="#">China</a>
VGA driver ver.21.30.02.210727a_0827	Windows® 11 64bit	587MB	2021/10/8	<a href="#">Global</a> <a href="#">China</a>
ASRock Motherboard Utility ver.3.0.466	Windows® 11 64bit	59.40MB	2022/5/17	<a href="#">Global</a> <a href="#">China</a>
APP Shop ver.1.0.52	Windows® 11 64bit	3.91MB	2021/5/31	<a href="#">Global</a> <a href="#">China</a>
Nahimic3 Utility ver.210913_APO4	Windows® 11 64bit	85.3MB	2021/11/8	<a href="#">Global</a> <a href="#">China</a>
Norton Security ver.22.21.5	Windows® 11 64bit	232MB	2021/10/8	<a href="#">Global</a> <a href="#">China</a>
Restart to UEFI ver.1.0.9	Windows® 11 64bit	1.01MB	2021/10/8	<a href="#">Global</a> <a href="#">China</a>
[Beta] ASRock Motherboard Utility ver.3.0.441	Windows® 11 64bit	59.31MB	2021/12/14	<a href="#">Global</a> <a href="#">China</a>

After installation, double-click  on your desktop to access ASRock Live Update & APP Shop utility.

*\*You need to be connected to the Internet to download apps from the ASRock Live Update & APP Shop.*

## 2.2.2 UI Overview



**Category Panel:** The category panel contains several category tabs or buttons that when selected the information panel below displays the relative information.

**Information Panel:** The information panel in the center displays data about the currently selected category and allows users to perform job-related tasks.

**Hot News:** The hot news section displays the various latest news. Click on the image to visit the website of the selected news and know more.

## 2.2.3 Apps

When the "Apps" tab is selected, you will see all the available apps on screen for you to download.

### Installing an App

#### Step 1

Find the app you want to install.



The most recommended app appears on the left side of the screen. The other various apps are shown on the right. Please scroll up and down to see more apps listed.

You can check the price of the app and whether you have already installed it or not.


**Free** - The red icon displays the price or "Free" if the app is free of charge.

**Installed** - The green "Installed" icon means the app is installed on your computer.

#### Step 2

Click on the app icon to see more details about the selected app.


### Step 3


If you want to install the app, click on the red icon  to start downloading.



### Step 4


When installation completes, you can find the green "Installed" icon appears on the upper right corner.



To uninstall it, simply click on the trash can icon .

\*The trash icon may not appear for certain apps.

## Upgrading an App

You can only upgrade the apps you have already installed. When there is an available new version for your app, you will find the mark of "New Version"  appears below the installed app icon.



### Step 1

Click on the app icon to see more details.


### Step 2

Click on the yellow icon  to start upgrading.


## 2.2.4 BIOS & Drivers

### Installing BIOS or Drivers

When the "BIOS & Drivers" tab is selected, you will see a list of recommended or critical updates for the BIOS or drivers. Please update them all soon.



#### **Step 1**

Please check the item information before update. Click on  to see more details.

#### **Step 2**

Click to select one or more items you want to update.


#### **Step 3**

Click Update to start the update process.



## 2.2.5 Setting

In the "Setting" page, you can change the language, select the server location, and determine if you want to automatically run the ASRock Live Update & APP Shop on Windows startup.




## 2.3 ASRock Motherboard Utility (A-Tuning)

ASRock Motherboard Utility (A-Tuning) is ASRock's multi purpose software suite with a new interface, more new features and improved utilities.

### 2.3.1 Installing ASRock Motherboard Utility (A-Tuning)

ASRock Motherboard Utility (A-Tuning) can be downloaded from ASRock Live Update & APP Shop.

You can also download the utility from the ASRock's website: "<https://www.asrock.com>". Go to the product page of your motherboard, select "Support" > "Download" to download "ASRock Motherboard Utility".


After the installation, you will find the icon "ASRock Motherboard Utility (A-Tuning)" on your desktop. Double-click the "ASRock Motherboard Utility (A-Tuning)" icon , ASRock Motherboard Utility (A-Tuning) main menu will pop up.

### 2.3.2 Using ASRock Motherboard Utility (A-Tuning)

There are five sections in ASRock Motherboard Utility (A-Tuning) main menu: Operation Mode, OC Tweaker, System Info, FAN-Tastic Tuning and Settings.


#### Operation Mode

Choose an operation mode for your computer.



## OC Tweaker


Configurations for overclocking the system.



## System Info

View information about the system.

\*The System Browser tab may not appear for certain models.



## FAN-Tastic Tuning

Configure up to five different fan speeds using the graph. The fans will automatically shift to the next speed level when the assigned temperature is met.

**FAN-Tastic Tuning**

CPU FAN1

Start FAN Test

Fan Power	Fan Speed
100%	N/A RPM
90%	N/A RPM
80%	N/A RPM
70%	N/A RPM
60%	N/A RPM
50%	N/A RPM
40%	N/A RPM
30%	N/A RPM
20%	N/A RPM
10%	N/A RPM

Auto apply when program starts

Apply Cancel

**Description**

Configure different fan speeds for respective temperatures using the graph. The fans will automatically shift to the next speed level when the assigned temperature is met.

## Settings

Configure ASRock ASRock Motherboard Utility (A-Tuning). Click to select "Auto run at Windows Startup" if you want ASRock Motherboard Utility (A-Tuning) to be launched when you start up the Windows operating system.

**Settings**

Auto run at Windows Startup

Version : 3.0.466

**Description**

Configure ASRock A-Tuning.


## 2.4 Phantom Gaming Tuning

Phantom Gaming Tuning is ASRock's multi purpose software suite with a new interface, more new features and improved utilities.

### 2.4.1 Installing Phantom Gaming Tuning

Phantom Gaming Tuning can be downloaded from ASRock Live Update & APP Shop.

You can also download the utility from the ASRock's website: "<https://www.asrock.com>". Go to the product page of your motherboard, select "Support" > "Download" to download "ASRock Motherboard Utility".


After the installation, you will find the icon "Phantom Gaming Tuning" on your desktop. Double-click the "Phantom Gaming Tuning"  icon, Phantom Gaming Tuning main menu will pop up.

### 2.4.2 Using Phantom Gaming Tuning

There are five sections in Phantom Gaming Tuning main menu: Operation Mode, OC Tweaker, System Info, FAN-Tastic Tuning and Settings.

#### Operation Mode

Choose an operation mode for your computer.



## OC Tweaker


Configurations for overclocking the system.



## System Info

View information about the system.

\*The System Browser tab may not appear for certain models.



## FAN-Tastic Tuning

Configure up to five different fan speeds using the graph. The fans will automatically shift to the next speed level when the assigned temperature is met.

The screenshot displays the ASRock Phantom Gaming Tuning software interface, specifically the FAN-Tastic Tuning section. The window title is "ASRock Phantom Gaming Tuning". The interface includes a navigation bar with tabs for "Operation Mode", "OC Tweaker", "System Info", "FAN-Tastic Tuning", and "Settings". The "FAN-Tastic Tuning" tab is selected, showing a graph of Fan Speed (%) on the y-axis (0 to 100) and Temperature (C) on the x-axis (0 to 100). A red line on the graph shows the fan speed profile, which is constant at 30% until approximately 60°C, then rises to 50% at 65°C, 70% at 70°C, and 100% at 100°C. To the right of the graph is a table for configuring fan speeds:

Fan Power	Fan Speed
100%	N/A RPM
90%	N/A RPM
80%	N/A RPM
70%	N/A RPM
60%	N/A RPM
50%	N/A RPM
40%	N/A RPM
30%	N/A RPM
20%	N/A RPM
10%	N/A RPM

Below the table is a "Start FAN Test" button and an "Auto apply when program starts" checkbox. To the right of the table is a visual representation of a fan and a monitor. The "Settings" tab is active, showing the "Auto run at Windows Startup" checkbox checked. The "Description" section at the bottom states: "Configure different fan speeds for respective temperatures using the graph. The fans will automatically shift to the next speed level when the assigned temperature is met."

## Settings

Configure ASRock Phantom Gaming Tuning. Click to select "Auto run at Windows Startup" if you want Phantom Gaming Tuning to be launched when you start up the Windows operating system.


The screenshot displays the ASRock Phantom Gaming Tuning software interface, specifically the Settings section. The window title is "ASRock Phantom Gaming Tuning". The interface includes a navigation bar with tabs for "Operation Mode", "OC Tweaker", "System Info", "FAN-Tastic Tuning", and "Settings". The "Settings" tab is selected, showing the "Auto run at Windows Startup" checkbox checked. The "Description" section at the bottom states: "Configure ASRock Phantom Gaming." The version number "Version : 3.0.230" is visible in the bottom right corner.

## 2.5 ASRock Polychrome SYNC

ASRock Polychrome SYNC is a lighting control utility specifically designed for unique individuals with sophisticated tastes to build their own stylish colorful lighting system. Simply by connecting the LED strip, you can customize various lighting schemes and patterns, including Static, Breathing, Strobe, Cycling, Music, Wave and more.

### 2.5.1 Connecting the LED Strip

Connect your RGB LED strip to the **RGB LED Header** on the motherboard.



**RGB LED Header**



1. Never install the RGB LED cable in the wrong orientation; otherwise, the cable may be damaged.
2. Before installing or removing your RGB LED cable, please power off your system and unplug the power cord from the power supply. Failure to do so may cause damages to motherboard components.





1. Please note that the RGB LED strips do not come with the package.
2. The RGB LED header supports standard 5050 RGB LED strip (12V/G/R/B), with a maximum power rating of 3A (12V) and length within 2 meters.



## 2.5.2 Connecting the Addressable RGB LED Strip

Connect your Addressable RGB LED strip to the **Addressable LED Header** on the motherboard.



**Addressable LED Header**



1. Never install the RGB LED cable in the wrong orientation; otherwise, the cable may be damaged.
2. Before installing or removing your RGB LED cable, please power off your system and unplug the power cord from the power supply. Failure to do so may cause damages to motherboard components.




1. Please note that the RGB LED strips do not come with the package.
2. The RGB LED header supports WS2812B addressable RGB LED strip (5V/Data/GND), with a maximum power rating of 3A (5V) and length within 2 meters.

## 2.5.3 Installing ASRock Polychrome SYNC Utility

After connecting the required LED strips, download the ASRockPolychrome SYNC Utility from the ASRock Live Update & APP Shop. You can also download the utility from the ASRock's website: "<https://www.asrock.com>". Go to the product page of your motherboard, select "Support" > "Download" to download the ASRock Polychrome RGB.


Now you can adjust the RGB LED color through this utility and start coloring your PC style your way!



## 2.6 Nahimic Audio

Nahimic audio software provides an incredible high definition sound technology which boosts the audio and voice performance of your system. Nahimic Audio interface is composed of four tabs: Audio, Microphone, Sound Tracker and Settings.

Download this utility from the ASRock Live Update & APP Shop. You can also download the utility from the ASRock's website: "<https://www.asrock.com>". Go to the product page of your motherboard, select "Support" > "Download" to download the Nahimic utility.



There are four functions in Nahimic audio:

No.	Function	Description
1	Audio	From this tab, you can mute the current audio device, choose between four factory audio profiles, turn all audio effects on/off, restores the current profile to its default settings and access Surround Sound and various features.
2	Microphone	From this tab, you can mute the current mic device, choose between two factory mic profiles, turn/off all microphone effects, restore the current profile to its default settings, and access Static Noise Suppression and various features.
3	Sound Tracker	The Sound Tracker provides a visual indication localizing the sources of the sounds while in a game. These are represented by dynamic segments pointing the direction of the sounds: the more opaque they are, the stronger the sounds are.

- 
- 4**      Settings      From this tab, you can access all settings and information of the software.

## Chapter 3 UEFI SETUP UTILITY

### 3.1 Introduction

ASRock UEFI (Unified Extensible Firmware Interface) is a BIOS utility which offers tweak-friendly options in an advanced viewing interface. The UEFI system works with a USB mouse and offers users a faster, sleeker experience.

This BIOS utility can perform the Power-On Self-Test (POST) during system startup, record hardware parameters of the system, load operating system, and so on. The battery on the motherboard supplies the power needed to the CMOS when the system power is turned off, and the values configured in the UEFI utility are kept in the CMOS.

Please note that inadequate BIOS settings may cause system instability, malfunction or boot failure. We strongly recommend that you do not alter the UEFI default configurations or change the settings only with the assistance of a trained service person.

If the system becomes unstable or fails to boot after you change the setting, try to clear the CMOS values and reset the board to default values. See your motherboard manual for instructions.

#### 3.1.1 Entering BIOS Setup


You may run the UEFI SETUP UTILITY by pressing <F2> or <Del> right after you power on the computer; otherwise, the Power-On-Self-Test (POST) will continue with its test routines. If you wish to enter the UEFI SETUP UTILITY after POST, restart the system by pressing <Ctl> + <Alt> + <Delete>, or by pressing the reset button on the system chassis. You may also restart by turning the system off and then back on.

This setup guide explains how to use the UEFI SETUP UTILITY to configure all the supported system. The screenshots in this manual are for reference only. UEFI Settings and options may vary owing to different BIOS release versions or CPU installed. Please refer to the actual BIOS version of the motherboard you purchased for detailed screens, settings and options.

### 3.1.2 EZ Mode

The EZ Mode screen appears when you enter the BIOS setup program by default. EZ mode is a dashboard which contains multiple readings of the system's current status. You can check the most crucial information of your system, such as CPU speed, DRAM frequency, SATA information, fan speed, etc.

Press <F6> or click the "Advanced Mode" button at the upper right corner of the screen to switch to "Advanced Mode" for more options.



### 3.1.3 Advanced Mode

The Advanced Mode provides more options to configure the BIOS settings. Refer to the following sections for the detailed configurations.

To access the EZ Mode, press <F6> or click the "EZ Mode" button at the upper right corner of the screen.

### 3.1.4 UEFI Menu Bar

The top of the screen has a menu bar with the following selections:

<b>Main</b>	For setting system time/date information
<b>OC Tweaker</b>	For overclocking configurations
<b>Advanced</b>	For advanced system configurations
<b>Tool</b>	Useful tools
<b>H/W Monitor</b>	Displays current hardware status
<b>Security</b>	For security settings
<b>Boot</b>	For configuring boot settings and boot priority
<b>Exit</b>	Exit the current screen or the UEFI Setup Utility



*Because the UEFI software is constantly being updated, the following UEFI setup screens and descriptions for reference purpose only, and may vary from the latest BIOS and do not exactly match what you see on your screen.*



*Please realize that there is a certain risk involved with overclocking, including adjusting the setting in the BIOS, applying Untied Overclocking Technology, or using third-party overclocking tools. Overclocking may affect your system's stability, or even cause damage to the components and devices of your system. It should be done at your own risk and expense. We are not responsible for possible damage caused by overclocking.*

### 3.1.5 Navigation Keys

Use <←→> key or <→> key to choose among the selections on the menu bar, and use <↑> key or <↓> key to move the cursor up or down to select items, then press <Enter> to get into the sub screen. You can also use the mouse to click your required item.

Please check the following table for the descriptions of each navigation key.

Navigation Key(s)	Description
+ / -	To change option for the selected items
<Tab>	Switch to next function
<PGUP>	Go to the previous page
<PGDN>	Go to the next page
<HOME>	Go to the top of the screen
<END>	Go to the bottom of the screen
<F1>	To display the General Help Screen
<F4>	Search for BIOS item
<F6>	Switch between Easy Mode and Advanced Mode
<F7>	Discard changes and exit the SETUP UTILITY
<F9>	Load optimal default values for all the settings
<F10>	Save changes and exit the SETUP UTILITY
<F12>	Print screen
<ESC>	Jump to the Exit Screen or exit the current screen



## 3.2 Main Screen


When you enter the UEFI SETUP UTILITY, the Main screen will appear and display the system overview.



*Because the UEFI software is constantly being updated, the following UEFI setup screens and descriptions are for reference purpose only, and they may not exactly match what you see on your screen. Options may also vary depending on the features of your motherboard. Please refer to the BIOS of your motherboard for the actual settings and options.*

### 3.3 OC Tweaker Screen

In the OC Tweaker screen, you can set up overclocking features.



#### Performance Preset

Allows you to select the pre-configured performance presets. Configuration options vary by models. Configuration options may includes [Auto] [PBO Enabled] [PBO and Tjmax = 85°C] [PBO, Tjmax = 85°C and Curve Optimizer -20mV] [PBO, Tjmax = 85°C and Curve Optimizer -30mV] [PBO, Tjmax = 85°C and Curve Optimizer -40mV] and so on.

#### Platform Thermal Throttle Limit(TjMax)

Allows you to decrease the maximum allowed processor temperature (celsius).

#### GFX Overclocking

Allow you configure GFX Overclocking settings.

Configuration options: [Auto] [Customize]

#### DRAM Frequency

If [Auto] is selected, the motherboard will detect the memory module(s) inserted and assign the appropriate frequency automatically.

#### DRAM Profile Configuration

Press [Enter] to configure DRAM profile.

## DRAM Profile Setting

Loads EXPO/XMP settings to overclock the DDR5 memory and perform beyond standard specifications.

## DRAM Performance Mode

Allows you to configure DRAM Performance Mode settings.

## DRAM Timing Configuration

Press [Enter] to configure DRAM Timing.

### DRAM Bus Control Configuration

Allows you to configure DRAM Bus Control settings.

### DFE Read Training

The item performs 2D Read Training with DFE on.

Configuration options: [Auto] [Disabled] [Enabled]

### Gear Down Mode

Configure the Gear Down Mode.

### CAS# Latency (tCL)

The time between sending a column address to the memory and the beginning of the data in response.

### RAS# to CAS# Delay to Read (tRCDRD)

The number of clock cycles required between the opening of a row of memory and accessing columns within it.

### Row Precharge Time (tRP)

The number of clock cycles required between the issuing of the precharge command and opening the next row.

### RAS# Active Time (tRAS)

The number of clock cycles required between a bank active command and issuing the precharge command.

### RAS# Cycle Time (tRC)

The number of memory clock cycles from activate command to another activate command.

### **Write Recovery Time (tWR)**

The amount of delay that must elapse after the completion of a valid write operation, before an active bank can be precharged.

### **Refresh Cycle Time (tRFC1)**

Specifies the Refresh Recovery Delay Time.

### **Refresh Cycle Time (tRFC2)**

Specifies the Refresh Recovery Delay Time.

### **Refresh Cycle Time (tRFCsb)**

Specifies the Refresh Recovery Delay Time.

### **Read to Precharge (tRTP)**

The number of clocks that are inserted between a read command to a row pre-charge command to the same rank.

### **RAS to RAS Delay (tRRD<sub>L</sub>)**

The number of clocks between two rows activated in different banks of the same rank.

### **RAS to RAS Delay (tRRD<sub>S</sub>)**

The number of clocks between two rows activated in different banks of the same rank.

### **Four Activate Window (tFAW)**

Specifies the time window in which four activates are allowed the same rank.

### **Write to Read Delay (tWTR<sub>L</sub>)**

The number of clocks between the last valid write operation and the next read command to the same internal bank.

### **Write to Read Delay (tWTR<sub>L</sub>)**

The number of clocks between the last valid write operation and the next read command to the same internal bank.

### **TrdrdSCL**

The minimum number of cycles from the last clock of virtual CAS of the first read-burst operation to the clock in which CAS is asserted for a following read-burst operation in the same chipselect in the same bank group.

### TrdrdSc

The minimum number of cycles from the last clock of virtual CAS of the first read-burst operation to the clock in which CAS is asserted for a following read-burst operation in the same chipselect.

### TrdrdSd

The minimum number of cycles from the last clock of virtual CAS of the first read-burst operation to the clock in which CAS is asserted for a following read-burst operation in the same DIMM.

### TrdrdDd

The minimum number of cycles from the last clock of virtual CAS of the first read-burst operation to the clock in which CAS is asserted for a following read-burst operation in a different DIMM.

### TwrrwrSCL

The minimum number of cycles from the last clock of virtual CAS of a first write-burst operation to the clock in which CAS is asserted for a following write-burst operation in the same bank group.

### TwrrwrSc

The minimum number of cycles from the last clock of virtual CAS of the first write-burst operation to the clock in which CAS is asserted for a following write-burst operation in the same chipselect.

### TwrrwrSd

The minimum number of cycles from the last clock of virtual CAS of the first write-burst operation to the clock in which CAS is asserted for a following write-burst operation in the same DIMM.

### TwrrwrDd

The minimum number of cycles from the last clock of virtual CAS of the first write-burst operation to the clock in which CAS is asserted for a following write-burst operation in a different DIMM.

### Twrrrd

The minimum number of cycles from the last clock of virtual CAS of the first write-burst operation to the clock in which CAS is asserted for a following read-burst operation.

## Trdwr

The minimum number of cycles from the last clock of virtual CAS of the first read-burst operation to the clock in which CAS is asserted for a following write-burst operation.

## VDDIO Voltage (VDDIO\_MEM\_S3)

VDDIO is a voltage for the DDR bus signaling (PHY), and it is derived from your DRAM Voltage (VDDIO\_MEM\_S3). As a result, VDDP voltage can approach but not exceed your DRAM Voltage.  $VDDIO > VDDP + 0.1V$ ;  $VDDIO + 0.1V > VDD\_SOC$

## DRAM VDD Voltage

Allows you to configure the VDD Voltage supported by PMIC at DRAM side.

## DRAM VDDQ Voltage

Allows you to configure the VDDQ Voltage supported by PMIC at DRAM side.

## DRAM VPP Voltage

Allows you to configure the VPP Voltage supported by PMIC at DRAM side.

## Infinity Fabric Frequency

Allows you to set Infinity Fabric frequency (FCLK). FCLK must be less than MCLK for the best performance in most cases.

## UCLK DIV1 MODE

Allows you to set UCLK DIV1 mode.

## SoC/Uncore OC Voltage (VDD\_SOC)

Allows you to specify the SoC/uncore voltage (VDD\_SOC) to support memory and Infinity Fabric overlocking. VDD\_SOC also determines the GPU voltage on processors with integrated graphics.

## VDD Misc Voltage

VDDG is supply for the fabric data path and is derived from VDDCR\_MISC. When memory overlocking, increasing VDDG may be necessary.

## VDDG CCD Voltage

VDDG is supply for the fabric data path and is derived from VDDCR\_MISC. When memory overlocking, increasing VDDG may be necessary.

## VDD IOD Voltage

VDDG is supply for the fabric data path and is derived from VDDCR\_MISC. When memory overclocking, increasing VDDG may be necessary.

## VDDP Voltage

VDDP is a voltage for the DDR5 bus signaling(PHY), and it is derived from VDDIO\_MEM\_S3. VDDP voltage can approach but not exceed VDDIO Voltage.

## Overclock Mode(Bus Speed)

Allows you to select the overclock mode. Warning! When overclocking also the PCIe, PCI, SATA and USB busses will be overclocked which may cause instability or failure. Please install an operating system and the drivers required before overclocking, or else your HDD's may be undetectable. Overclocking is not supported if the monitor is connected via the onboard D-Sub/VGA connector.

Configuration options: [Auto] [Manual]

## External Voltage Settings

Press [Enter] to configure the voltage options.

### VDDCR\_SOC Voltage

Input voltage for the processor by the external voltage regulator.

Configuration options: [Auto] [Offset Mode]

### VDD\_MISC Voltage

Input voltage for the processor by the external voltage regulator.

Configuration options: [Auto] [Offset Mode]

### PCH 1.05V Voltage

Configure the voltage for the PCH 1.05 Voltage.

### VDD\_MISC\_S5 Voltage

Configure the voltage for the VDD\_MISC\_S5 Voltage.

## Save User Default

Type a profile name and press enter to save your settings as user default.

## Load User Default

Loads previously saved user defaults.

---

### Save User UEFI Setup Profile to Disk

Saves current UEFI settings as an user default profile to disk.

### Load User UEFI Setup Profile to Disk

Loads previously saved user defaults from the disk.



## 3.4 Advanced Screen

In this section, you may set the configurations for the following items: CPU Configuration, PCI Configuration, Onboard Devices Configuration, Storage Configuration, ACPI Configuration, USB Configuration, Trusted Computing, AMD CBS, AMD PBS and AMD Overclocking.



*Setting wrong values in this section may cause the system to malfunction.*

### BIOS Setup Text Color

Allows you to select the BIOS Setup text color.

Configuration options: [Default] [Deep Red] [Red] [Orange] [Yellow] [Light Green] [Green] [Light Blue] [Blue] [Deep Blue] [Purple] [Color Code]

### Mouse Relative Movement Delta

Allows you to set Mouse Relative Movement Delta. Relative Mouse is a method of translating mouse movements as a delta from the last mouse position rather than a move to an absolute position on the screen.

Configuration options: [X 1] [X 2] [X 4]

### Active Page on Entry

Allows you to select the default page when entering the UEFI setup utility.

---

Configuration options: [Main] [OC Tweaker] [Advanced] [Tool] [H/W Monitor]  
[Security] [Boot] [Exit]

## Full HD UEFI BIOS

[Auto]

When [Auto] is selected, the resolution will be set to 1920 x 1080 if the monitor supports Full HD resolution. If the monitor does not support Full HD resolution, then the resolution will be set to 1024 x 768.

[Disabled]

When [Disabled] is selected, the resolution will be set to 1024 x 768 directly.

## UEFI Setup Style

Select the default mode when entering the UEFI setup utility.

Configuration options: [Advanced Mode] [Easy Mode]

## 3.4.1 CPU Configuration



### AMD fTPM Switch

Use this to enable or disable AMD CPU fTPM.

Configuration options: [AMD CPU fTPM] [Route to SPI TPM] [Disabled]

### PSS Support

Allows you to enable or disable the generation of ACPI\_PPC, \_PSS, and \_PCT objects.

### NX Mode

Allows you to enable or disable No-execute page protection function.

### SMT Mode

This item can be used to disable symmetric multithreading. To re-enable SMT, a power cycle is needed after selecting [Auto].

Warning: S3 is not supported on systems where SMT is disabled.

### AVX512

This item can be used to enable or disable AVX512.

## 3.4.2 PCI Configuration



### Above 4G Decoding

Globally enables or disables 64-bit capable devices to be decoded in Above 4G Address Space (only if the system supports 64-bit PCI Decoding).

### Re-Size BAR Support

If system has Resizable BAR capable PCIe Devices, this option enables or disables Resizable BAR Support.

### Above 4GB MMIO Limit


Allows you to select Above 4GB MMIO Limit to 38~43 bits limit. This option works only when "Above 4G decoding" is enabled.

Configuration options: [40bit (1TB)] [41bit (2TB)] [42bit (4TB)] [43bit (8TB)] [44bit (16TB)] [45bit (32TB)] [46bit (64TB)] [47bit (126TB)] [48bit (256TB)]

### SR-IOV Support

If system has SR-IOV capable PCIe Devices, this option enables or disables Single Root IO Virtualization Support.

### 3.4.3 Onboard Devices Configuration



#### Turn On Onboard LED in S5

Allows you to turn on/off the LED in the ACPI S5 state.

[Disabled] Select this item to turn off the LED in the ACPI S5 state.

[Enabled] Select this item to turn on the LED in the ACPI S5 state.

#### Restore Onboard LED Default

Allows you to restore Onboard LED default value.

[Disabled] Select this item to not to restore Onboard LED default value.

[Apply] Select this item to restore Onboard LED default value.

#### RGB LED

Allows you to enable or disable the RGB LED.

[On] Select this item to enable the RGB LED.

[Off] Select this item to disable the RGB LED.

#### Display Priority

Allows you to select the Display Priority.

Configuration options: [Internal Graphic] [External Graphic]

---

## Onboard HD Audio

Allows you to enable or disable onboard HD audio.

## Onboard LAN

Allows you to enable or disable Onboard LAN.

## WAN Radio


Allows you to configure the WiFi module's connectivity.

## BT On/Off

Allows you to enable or disable the bluetooth.

Configuration options: [Auto] [Disabled] [Enabled]


## 3.4.4 Storage Configuration



### Third Party SATA3 Hot Plug

This item allows you to enable or disable Hot Plug for Third Party SATA3 port.

## 3.4.5 ACPI Configuration



### Suspend to RAM

It is recommended to select auto for ACPI S3 power saving.

Configuration options: [Disabled] [Auto]

### Restore on AC/Power Loss

Allows you to select the power state after a power failure.

[Power Off] Select this item and the power will remain off when the power recovers.

[Power On] Select this item and the system will start to boot up when the power recovers.

Configuration options: [Power On] [Power Off]

### Deep Sleep

Allows you to configure deep sleep mode for power saving when the computer is shut down. We recommend disabling Deep Sleep for better system compatibility and stability.

Configuration options: [Disabled] [Enabled in S5] [Enabled in S4 & S5]

### USB Device Power on (USB\_1)

Power on system by USB Keyboard or USB Mouse. Please connect USB keyboard or USB mouse to the specified port. Because AM5 socket CPU and AGESA might be



updated, the function of this option will be subject to change without notice.

Configuration options: [Enabled] [Disabled]

### USB Power delivery in Soft Off state (S5)

The item allows you to enable or disable USB Power delivery in Soft Off state (S5).

### PCIe Devices Power On

[Enabled] Select this item to allow the system to be waked up by a PCIe device and enable wake on LAN.

[Disabled] Select this item to disallow the system to be waked up by a PCIe device and disable wake on LAN.

### RTC Alarm Power On

[Enabled]

Select this item to allow the system to be waked up by the real time clock alarm.

[Disabled]

Select this item to disallow the system to be waked up by the real time clock alarm.

[By OS]

Select this item to let it be handled by your operating system.

## 3.4.6 USB Configuration



### XHCI Hand-off

This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

Configuration options: [Enabled] [Disabled]

### USB Mass Storage Driver Support

This item allows you to enable or disable USB Mass Storage Driver Support.

## 3.4.7 Trusted Computing



NOTE: Options vary depending on the version of your connected TPM module.

### Security Device Support

Allows you to enable or disable BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

### Active PCR banks

This item displays active PCR Banks.

### Available PCR Banks

This item displays available PCR Banks.

### SHA256 PCR Bank

Allows you to enable or disable SHA256 PCR Bank.

### SHA384 PCR Bank

Allows you to enable or disable SHA384 PCR Bank.

### Pending Operation

Allows you to schedule an Operation for the Security Device.

NOTE: Your computer will reboot during restart in order to change State of the Device.

Configuration options: [None] [TPM Clear]

---

## Platform Hierarchy

Allows you to enable or disable Platform Hierarchy.

## Storage Hierarchy

Allows you to enable or disable Storage Hierarchy.

## Endorsement Hierarchy

Allows you to enable or disable Endorsement Hierarchy.

## Physical Presence Spec version

Allows you to select this item to tell OS to support PPI spec version 1.2 or 1.3. Please note that some HCK tests might not support version 1.3.

Configuration options: [1.2] [1.3]

## Device Select


Use this item to select the TPM device to be supported.

[TPM 1.2] Select this item to restrict support to TPM 1.2 devices.

[TPM 2.0] Select this item to restrict support to TPM 2.0 devices.

[Auto] Select this item to support both TPM 1.2 and 2.0 devices, with the default set to TPM 2.0 devices. If TPM 2.0 devices are not found, TPM 1.2 devices will be enumerated.

## 3.4.8 AMD CBS



*NOTE: Options may vary depending on the motherboard. Please refer to the BIOS of your motherboard for the actual settings and options.*

### CPU Common Options

Press [Enter] to configure CPU Common options.

#### Thread Enablement

Press [Enter] to configure Thread Enablement options.

#### SMT Control

The item can be used to disable symmetric multithreading. To re-enable SMT, a POWER CYCLE is needed after selecting the "Auto" option.

#### Prefetcher Settings

Press [Enter] to configure Prefetcher Settings.

#### L1 Stream HW Prefetcher

Allows you to enable or disable L1 Stream HW Prefetcher.

Configuration options: [Auto] [Disabled] [Enabled]

#### L2 Stream HW Prefetcher

Allows you to enable or disable L2 Stream HW Prefetcher.

Configuration options: [Auto] [Disabled] [Enabled]

#### L1 Stride Prefetcher

Uses memory access history of individual instructions to fetch additional lines when each access is a constant distance from the previous.

Configuration options: [Auto] [Disabled] [Enabled]

### L1 Region Prefetcher

Uses memory access history to fetch additional lines when the data access for a given instruction tends to be followed by other data accesses.

Configuration options: [Auto] [Disabled] [Enabled]

### L1 Burst Prefetcher

Use this item to enable or disable L1 Burst Prefetch Mode.

Configuration options: [Auto] [Disabled] [Enabled]

### L2 Up/Down Prefetcher

Uses memory access history to determine whether to fetch the next or previous line for all memory accesses.

Configuration options: [Auto] [Disabled] [Enabled]

### Core Watchdog

Press [Enter] to configure Core Watchdog options.

#### Core Watchdog Timer Enable

Allows you to enable or disable CPU Watchdog Timer.

Configuration options: [Auto] [Disabled] [Enabled]

#### Core Watchdog Timer Interval

When "Core Watchdog Timer Enable" is set to [Enabled], you can use this item to select CPU Watchdog Timer interval.

#### Core Watchdog Timer Severity

When "Core Watchdog Timer Enable" is set to [Enabled], you can use this item to specify the CPU watch dog timer severity.

Configuration options: [No Error] [Transparent] [Corrected] [Deferred] [Uncorrected] [Fatal] [Auto]

### DF Common Options

Press [Enter] to configure DF Common options.

#### Memory Addressing

Press [Enter] to configure Memory Addressing options.

#### Memory interleaving

The item allows for disabling memory channel interleaving.

#### Memory interleaving size

The item controls the memory interleaving size. The valid values are AUTO, 256 bytes,

1 Kbytes or 2Kbytes. This determines the starting address of the interleave (bit 8, 9, 10 or 11).

### DRAM map inversion

Inverting the map will cause the highest memory channels to get assigned the lowest addresses in the system.

### Location of private memory regions

The item controls whether or not the private memory regions (PSP, SMU and CC6) are at the top of DRAM, at the top of 1<sup>st</sup> DRAM pair or distributed. Note that distributed requires memory on all dies. Note that it will always be at the top of DRAM if some dies don't have memory regardless of this option's setting.

Configuration options: [Auto] [Distributed] [Consolidated] [Consolidated to 1st DRAM pair]

### ACPI

Press [Enter] to configure ACPI options.

### ACPI SRAT L3 Cache As NUMA Domain

[Enabled]: Each CCX in the system will be declared as a separate NUMA domain.

[Disabled]: Memory Addressing \ NUMA nodes per socket will be declared.

[Auto] Select this item to apply the default setting.

### Disable DF to external downstream IP Sync Flood Propagation

The item allows you to disable Error propagation to UMC or any downstream slaves eg. ECH. Use this to avoid reset in failure scenario.

Configuration options: [Auto] [Sync flood disabled] [Sync flood enabled]

### Disable DF sync flood propagation

The item allows you to disable propagation from PIE to other DF components and eventually to SDP ports.

Configuration options: [Auto] [Sync flood disabled] [Sync flood enabled]

### Freeze DF module queues on error

The item allows you to enable freezing of all DF queues on error and also forces a sync flood on HWA even if MCAs are disabled.

Configuration options: [Auto] [Enabled] [Disabled]

### DR Cstates

When DF Cstate feature is enabled, FW programs the registers required to enable this feature. For auto option, it means this option will be synchronized with Global C State.

Configuration options: [Auto] [Enabled] [Disabled]

### PSP error injection support

[True] Select this item to enable error injection.

[False] Select this item to disable error injection.

## UMC Common Options

Press [Enter] to configure UMC Common options.

### DDR Options

Press [Enter] to configure DDR Options.

### DDR Timing Configuration

Press [Enter] to adjust DDR Timing configuration.

### DDR Bus Configuration

Press [Enter] to adjust DDR Bus configuration.

### Processor CK drive strengths

Use this item to specify the Processor CK drive strengths.

Configuration options: [Auto] [120.0 Ohm] [60.0 Ohm] [Deferred] [40.0 Ohm] [30.0 Ohm]

### Processor CC drive strengths

Use this item to specify the Processor CC drive strengths.

Configuration options: [Auto] [120.0 Ohm] [60.0 Ohm] [Deferred] [40.0 Ohm] [30.0 Ohm]

### Processor CS drive strengths

Use this item to specify the Processor CS drive strengths.

Configuration options: [Auto] [120.0 Ohm] [60.0 Ohm] [Deferred] [40.0 Ohm] [30.0 Ohm]

### CA ODT GroupA

Use this item to specify the CA ODT.

Configuration options: [Auto] [RTT\_OFF (Disable)] [RZQ/0.5 (480)] [RZQ/1 (240)] [RZQ/2 (120)] [RZQ/3 (80)] [RZQ/4 (60)] [RFU] [RZQ/6 (40)]

### CK ODT GroupA

Use this item to specify the CK ODT.

Configuration options: [Auto] [RTT\_OFF (Disable)] [RZQ/0.5 (480)] [RZQ/1 (240)] [RZQ/2 (120)] [RZQ/3 (80)] [RZQ/4 (60)] [RFU] [RZQ/6 (40)]

### CS ODT GroupA

Use this item to specify the CS ODT.

Configuration options: [Auto] [RTT\_OFF (Disable)] [RZQ/0.5 (480)] [RZQ/1 (240)] [RZQ/2 (120)] [RZQ/3 (80)] [RZQ/4 (60)] [RFU] [RZQ/6 (40)]

### CA ODT GroupB



Use this item to specify the CA ODT.

Configuration options: [Auto] [RTT\_OFF (Disable)] [RZQ/0.5 (480)] [RZQ/1 (240)] [RZQ/2 (120)] [RZQ/3 (80)] [RZQ/4 (60)] [RFU] [RZQ/6 (40)]

### CK ODT GroupB

Use this item to specify the CK ODT.

Configuration options: [Auto] [RTT\_OFF (Disable)] [RZQ/0.5 (480)] [RZQ/1 (240)] [RZQ/2 (120)] [RZQ/3 (80)] [RZQ/4 (60)] [RFU] [RZQ/6 (40)]

### CS ODT GroupB

Use this item to specify the CS ODT.

Configuration options: [Auto] [RTT\_OFF (Disable)] [RZQ/0.5 (480)] [RZQ/1 (240)] [RZQ/2 (120)] [RZQ/3 (80)] [RZQ/4 (60)] [RFU] [RZQ/6 (40)]

### Processor ODT Impedance Pull Up P0

Use this item to specify the Processor ODT Impedance Pull Up P0.

### Processor ODT Impedance Pull Down P0

Use this item to specify the Processor ODT Impedance Pull Down P0.

### Processor DQ drive strengths Pull Up P0

Use this item to specify the Processor DQ Impedance Pull Up P0.

### Processor DQ drive strengths Pull Down P0

Use this item to specify the Processor DQ Impedance Pull Down P0.

### Dram ODT Impedance RTT\_NOM\_WR P0

Use this item to specify the Dram ODT impedance RTT\_NOM\_WR P0.

### Dram ODT Impedance RTT\_NOM\_RD P0

Use this item to specify the Dram ODT impedance RTT\_NOM\_RD P0.

### Dram ODT Impedance RTT\_WR P0

Use this item to specify the Dram ODT impedance RTT\_WR P0.

### Dram ODT Impedance RTT\_PARK P0

Use this item to specify the Dram ODT impedance RTT\_PARK P0.

### Dram ODT Impedance DQS\_RTT\_PARK P0

Use this item to specify the Dram ODT impedance DQS\_RTT\_PARK P0.

### Dram DQ drive strengths Pull Up P0

Use this item to specify the Dram DQ drive strengths Pull Up P0.

### Dram DQ drive strengths Pull Down P0

Use this item to specify the Dram DQ drive strengths Pull Down P0.

### Processor ODT Impedance Pull Up P1

Use this item to specify the Processor ODT Impedance Pull Up P1.

### Processor ODT Impedance Pull Down P1

Use this item to specify the Processor ODT Impedance Pull Down P1.

### Processor DQ drive strengths Pull Up P1

Use this item to specify the Processor DQ Impedance Pull Up P1.

### Processor DQ drive strengths Pull Down P1

Use this item to specify the Processor DQ Impedance Pull Down P1.

### Dram ODT Impedance RTT\_NOM\_WR P1

Use this item to specify the Dram ODT impedance RTT\_NOM\_WR P1.

### Dram ODT Impedance RTT\_NOM\_RD P1

Use this item to specify the Dram ODT impedance RTT\_NOM\_RD P1.

### Dram ODT Impedance RTT\_WR P1

Use this item to specify the Dram ODT impedance RTT\_WR P1.

### Dram ODT Impedance RTT\_PARK P1

Use this item to specify the Dram ODT impedance RTT\_PARK P1.

### Dram ODT Impedance DQS\_RTT\_PARK P1

Use this item to specify the Dram ODT impedance DQS\_RTT\_PARK P1.

### Dram DQ drive strengths Pull Up P1

Use this item to specify the Dram DQ drive strengths Pull Up P1.

### Dram DQ drive strengths Pull Down P1

Use this item to specify the Dram DQ drive strengths Pull Down P1.

### Processor ODT Impedance Pull Up P3

Use this item to specify the Processor ODT Impedance Pull Up P3.

### Processor ODT Impedance Pull Down P3

Use this item to specify the Processor ODT Impedance Pull Down P3.

### Processor DQ drive strengths Pull Up P3

Use this item to specify the Processor DQ Impedance Pull Up P3.

### Processor DQ drive strengths Pull Down P3

Use this item to specify the Processor DQ Impedance Pull Down P3.

### Dram ODT Impedance RTT\_NOM\_WR P3

Use this item to specify the Dram ODT impedance RTT\_NOM\_WR P3.

**Dram ODT Impedance RTT\_NOM\_RD P3**

Use this item to specify the Dram ODT impedance RTT\_NOM\_RD P3.

**Dram ODT Impedance RTT\_WR P3**

Use this item to specify the Dram ODT impedance RTT\_WR P3.

**Dram ODT Impedance RTT\_PARK P3**

Use this item to specify the Dram ODT impedance RTT\_PARK P3.

**Dram ODT Impedance DQS\_RTT\_PARK P3**

Use this item to specify the Dram ODT impedance DQS\_RTT\_PARK P3.

**Dram DQ drive strengths Pull Up P3**

Use this item to specify the Dram DQ drive strengths Pull Up P3.

**Dram DQ drive strengths Pull Down P3**

Use this item to specify the Dram DQ drive strengths Pull Down P3.

**DDR Controller Configuration**

Press [Enter] to adjust DDR Controller configuration.

**DDR Power Options**

Press [Enter] to configure DDR Power options.

**Power Down Enable**

Allows you to enable or disable DDR power down mode.

**DDR RAS**

Press [Enter] to configure DDR RAS options.

**Disable Memory Error Injection**

[True] Select this item to enable Memory Error Injection.

[False] Select this item to disable Memory Error Injection.

[Auto] Select this item to apply the default setting.

**DDR ECC Configuration**

Press [Enter] to adjust DDR ECC Configuration.

**ECC**

Allows you to enable or disable ECC. Auto will set ECC to be enabled.

Configuration options: [Auto] [Disabled] [Enabled]

**DDR Security**

Press [Enter] to configure DDR Security options.

**TSME**

Allows you to configure TSME setting.  
Configuration options: [Auto] [Disabled] [Enabled]

### Data Scramble

Allows you to configure Data Scramble setting.  
Configuration options: [Auto] [Disabled] [Enabled]

### DDR Addressing Options

Press [Enter] to configure DDR Addressing Options.

### Chipselect Interleaving

Interleaves memory blocks across the DRAM chip selected for node 0.  
Configuration options: [Auto] [Disabled]

### Address Hash Bank

Allows you to enable or disable bank address hashing.  
Configuration options: [Auto] [Disabled] [Enabled]

### Address Hash CS

Allows you to enable or disable CS address hashing.  
Configuration options: [Auto] [Disabled] [Enabled]

### Address Hash Subchannel

Allows you to enable or disable sub-channel address hashing.

### BankSwapMode

Allows you to configure BankSwapMode.  
Configuration options: [Auto] [Disabled] [Swap APU]

### DDR Training Options

Press [Enter] to configure DDR Training Options.

### DFE Read Training

The item performs 2D Read Training with DFE on.  
Configuration options: [Auto] [Disabled] [Enabled]

### DRAM PDA Enumerate ID Programming Mode

Allows you to configure DRAM PDA Enumerate ID Programming Mode.  
Configuration options: [Auto] [Sequential PDA enumeration mode] [Legacy PDA enumeration mode]

### TX DFE Taps

Allows you to specifies the number of TX DFE taps.

### PPT Control

Allows you to specifies the PPT Control.

## DDR Training Runtime Reduction

[Auto]: Default code behavior. If OC is ENABLED, DDR Training Runtime Reduction will be DISABLED by DEFAULT.

[Disabled]: Force to Disable DDR Training Runtime Reduction.

[Enabled]: Force to Enable DR Training Runtime Reduction.

## RX Burst Length

Use this item to configure Extended sequence for read training.

AUTO - Default code behavior.

1x burst length

2x burst length

4x burst length

8x burst length

## TX Burst Length

Use this item to configure Extended sequence for write training.

AUTO - Default code behavior.

1x burst length

2x burst length

4x burst length

8x burst length

## RX2D\_TrainOpt

Use this item to configure RX2D\_TrainOpt settings.

## RX2D\_DFE

Use this item to force Rx DFE on or off.

## RX2D Voltage Step Size (2<sup>n</sup>)

0 = 1 DAC setting between checked values

1 = 2 DAC setting between checked values

2 = 4 DAC setting between checked values

3 = 8 DAC setting between checked values

## RX2D Delay Step Size (2<sup>n</sup>)

0 = 1 LCDL delays between checked values

1 = 2 LCDL delays between checked values

2 = 4 LCDL delays between checked values

3 = 8 LCDL delays between checked values

## TX2D\_TrainOpt

Use this item to configure TX2D\_TrainOpt settings.

## TX2D\_DFE

Use this item to force Tx DFE on or off.

## TX2D Voltage Step Size (2^n)

0 = 1 DAC setting between checked values

1 = 2 DAC setting between checked values

2 = 4 DAC setting between checked values

3 = 8 DAC setting between checked values

## TX2D Delay Step Size (2^n)

0 = 1 LCDL delays between checked values

1 = 2 LCDL delays between checked values

2 = 4 LCDL delays between checked values

3 = 8 LCDL delays between checked values

## TX2D Voltage Step size Multiplier

0 = Voltage Step Size is not modified

1 = Voltage Step Size is not multiplied by 16

## RX DFE Taps

Allows you to specifies the number of RX DFE taps.

## DDR Memory MBIST

Press [Enter] to configure DDR Memory MBIST.

## MBIST Enable

Allows you to enable or disable Memory MBIST.

Configuration options: [Auto] [Disabled] [Enabled]

## MBIST Test Mode

Allows you to select MBIST Test Mode - Interface Mode (Tests Single and Multiple CS transactions and Basic Connectivity) or Data Eye Mode (Measure Volage vs. Timing).

Configuration options: [Auto] [Interface Mode] [Data Eye Mode] [Both]

## MBIST Aggressors

Allows you to enable or disable MBIST aggressor test.

Configuration options: [Auto] [Disabled] [Enabled]

## MBIST Per Bit Slave Die Reporting

When it is enabled, it reports 2D Data Eye Results in ABL Log for each DQ, Chipselect and Channel.

Configuration options: [Auto] [Disabled] [Enabled]

## DDR Data Eye

Press [Enter] to configure DDR Data Eye options.

## Pattern Select

Allows you to configure Pattern Select.

Configuration options: [PRBS] [SSO] [Both]

## Pattern Length

This token helps to determine the pattern length. The possible options are N=3...12.

## Aggressor Channel

This helps to read the aggressors channels. If it is enabled, you can read from one or more than one aggressor channel.

Configuration options: [Disabled] [1 Aggressor Channel] [3 Aggressor Channels] [7 Aggressor Channels]

## DDR Memory Features

Press [Enter] to configure DDR Memory Features.

## Memory Context Restore

Allows you to configure the memory context restore mode. When it is enabled, DRAM re-retaining is avoided if possible and the POST latency is minimized.

Configuration options: [Auto] [Disabled] [Enabled]

## DDR Turnaround Times

Press [Enter] to configure DDR Turnaround Times.

## Read Drift Adjustment

AUTO - Read Drift Adjustment 0

## Write Drift Adjustment

AUTO - Write Drift Adjustment 0

## NBIO Common Options

Press [Enter] to configure NBIO Common options.

### IOMMU

Allows you to enable or disable IOMMU.

Configuration options: [Auto] [Disabled] [Enabled]

### PCIe ARI Support

Allows you to enable or disable PCIe ARI Support.

Configuration options: [Auto] [Disabled] [Enabled]

### PCIe All Port ECRC

Allows you to enable or disable PCIe all port ECRC.

Configuration options: [Auto] [Disabled] [Enabled]

### Advanced Error Reporting (AER)

Allows you to enable or disable support for Advanced Error Reporting (AER).

Configuration options: [Auto][Supported] [Not Supported]

### PCIe ARI Enumeration

Allows you to enable or disable ARI Forwarding for each downstream port.

Configuration options: [Auto] [Disabled] [Enabled]

### GFX Configuration

Press [Enter] to configure GFX Configuration.

### dGPU Only Mode

Uses this item to disable GPU if dGPU is detected.

### UMA Version

Allows you to select UMA Version.

[Legacy] Select this item for UMA Legacy Version.

[Non-Legacy] Select this item for UMA Non Legacy Version.

[Auto] Select this item for Hybrid Secure.

### GPU Host Translation Cache

Allows you to enable or disable GPU Host Translation Cache.

Configuration options: [Auto] [Disabled] [Enabled]

### Audio Configuration

Press [Enter] to configure Audio Configuration.

Configuration options: [Auto] [Disabled] [Enabled]

### NB Azalia

Allows you to enable or disable HD Audio controller.

Configuration options: [Auto] [Disabled] [Enabled]

### Audio IOs

Allows you to configure Audio IOs controls.

### PCIe loopback Mode

Allows you to enable or disable PCIe loopback Mode.

Configuration options: [Auto] [Disabled] [Enabled]

### Persistence mode for legacy endpoints

Allows you to enable or disable persistence mode for legacy endpoints. Enable this option if some legacy PCIe devices are not detected.

### Retimer margining support

Auto is Disabled. Root port receiver margining support is enabled by default.

[Enabled]: enables support for margining a retimer.



[Disabled]: Retimer margining is not supported.

## FCH Common Options

Press [Enter] to configure FCH Common options.

### USB Configuration Options

Press [Enter] to configure USB Configuration Options.

#### USB0 controller enable

Allows you to enable or disable USB0 controller.

#### USB1 controller enable

Allows you to enable or disable USB1 controller.

#### USB2 controller enable

Allows you to enable or disable USB2 controller.

#### USB0 2.0 port enable

Press [Enter] to configure USB0 2.0 port enable options.

#### USB0 2.0 port 0

Allows you to enable or disable USB0 2.0 port 0.

#### USB0 2.0 port 1

Allows you to enable or disable USB0 2.0 port 1.

#### USB1 2.0 port enable

Press [Enter] to configure USB1 2.0 port enable options.

#### USB1 2.0 port 0

Allows you to enable or disable USB1 2.0 port 0.

#### USB1 2.0 port 1

Allows you to enable or disable USB1 2.0 port 1.

#### USB2 2.0 port enable

Press [Enter] to configure USB2 2.0 port enable options.

#### USB2 2.0 port 0

Allows you to enable or disable USB2 2.0 port 0.

#### USB0 3.1 port enable

Press [Enter] to configure USB0 3.1 port enable options.

#### USB0 3.1 port 0

Allows you to enable or disable USB0 3.1 port 0.

#### USB0 3.1 port 1

Allows you to enable or disable USB0 3.1 port 1.

### **USB1 3.1 port enable**

Press [Enter] to configure USB1 3.1 port enable options.

### **USB1 3.1 port 0**

Allows you to enable or disable USB1 3.1 port 0.

### **USB1 3.1 port 1**

Allows you to enable or disable USB1 3.1 port 1.

### **FCH Spread Spectrum**

Allows you to select whether or not enable the Spread Spectrum Feature.

## **SMU Common Options**

Press [Enter] to configure SMU Common Options.

### **TDP Control**

[Auto] Select this item to use the default sustained power limit.

[Manual] Select this item to set customized sustained power limit.

### **ECO Mode**

Use this item to adjust CPU control limits to manage operation within a 65w thermal design power.

[Enabled]: Enables 65W processor power definition.

[Disabled]: System uses default processor power definition.

[Enabled - 105W]: Enables 105W processor power definition (170W OPNs only)

### **PPT Control**

[Auto] Select this item to use the default PPT Limits.

[Manual] Select this item to set customized PPT Limits.

### **Thermal Control**

[Auto] Select this item to use the default TctlMax.

[Manual] Select this item to set customized TctlMax.

### **TDC Control**

[Auto] Select this item to use the default TDC limits.

[Manual] Select this item to set customized TDC limits.

### **EDC Control**

[Auto] Select this item to use the default EDC limits.

[Manual] Select this item to set customized EDC limits.

### **VDDP Voltage Control**

[Auto] Select this item to use the default VDDP voltage.

[Manual] Select this item to set customized VDDP voltage.

### **Infinity Fabric Frequency and Dividers**

Allows you to set Infinity Fabric Frequency and Dividers.

[Auto] BIOS will configure this setting automatically.

### **SyncFifo Mode Override**

Allows you to enable or disable SyncFifo Mode Override. When it is set to [Auto], SyncFifo Mode is disabled.

Configuration options: [Auto] [Disabled] [Enabled]

### **Sustained PowerLimit**

Allows you to adjust the sustained power limit.

### **Fast PPT Limit**

Allows you to adjust the Fast PPT Limit.

### **Slow PPT Limit**

Allows you to adjust the Slow PPT Limit.

### **Slow PPT Time Constant**

Allows you to adjust the Slow PPT Time Constant (seconds).

### **GFXOFF**

[Enabled]: Enables the GFXOFF feature.

[Disabled]: Disables the GFXOFF feature.

## **SOC Miscellaneous Control**

Press [Enter] to configure Soc Miscellaneous Control.

### **Trusted Platform Module**

Allows you to enable or disable TPM physical presence.

### **Pluton Security Processor**

This option is used to enable or disable Pluton Security Processor.

### **DRTM Support**

This option is used to enable or disable DRTM support.

### **SMM Isolation Support**

This option is used to enable or disable SMM Isolation (as known as SMM Supervisor).

### **ABL Console Out Control**

[Enabled] Select this item to enable ConsoleOut Function for ABL.

[Disabled] Select this item to disable ConsoleOut Function for ABL.

## **PROM21 Chipset Common Options**

Press [Enter] to configure Chipset Common options.

### **PROM21 Chipset PCIe Port Configuration Options**

Press [Enter] to configure PROM21 Chipset PCIe Port Configuration Options.

### **PROM21 Chipset SATA Configuration Options**

Press [Enter] to configure PROM21 Chipset SATA Configuration Options.

### **PROM21 Chipset USB Configuration Options**

Press [Enter] to configure PROM21 Chipset USB Configuration Options.

### **USB port disablement phase**

This item is used to configure USB port disablement phase.

Configuration options: [Before BIOS Setup] [Before OS Boot] [Auto]

### **PROM21L.1/3/5 USB Port Configuration Options**

Press [Enter] to configure PROM21L.1/3/5 USB Port Configuration Options.

### **PROM21 Chipset SI Configuration Options**

Press [Enter] to configure PROM21 Chipset SI Configuration Options.

### **Enable Program SI values**

Allows you to enable or disable Program SI values. It will take effect after cold reset.

### **PROM21 Chipset Revision**

Allows you to configure PROM21 Chipset Revision setting.

Configuration options: [Auto] [A1] [A2]

### **Dual PROM21 port number/disable**


Allows you to set downstream port number for the second PROM21.

Configuration options: [Auto] [Disable] [Port 0] [Port 4] [Port 8]

### **PCIe Power Management Features**

Allows you to adjust PCIe Power Management Features settings.

## 3.4.9 AMD PBS



### AMD Firmware Version

Press [Enter] to view information of all AMD Firmware versions.

### Graphics Features

Press [Enter] to configure Graphics Features - HG, DGPU Features, and BOMACO.

#### HDMI FRL Test

This item allows you to select HDMI FRL PATH CAPS.

Configuration options: [Auto] [FRL 8GbEn] [FRL 10GbEn] [FRL 12GbEn]  
[Disabled]

#### HDMI 2.0 Support

This item allows you to enable or disable HDMI 2.0 Support. If Disabled, it decreases HDMI data rate to support longer HDMI cable.

### Discrete USB4 Features

Press [Enter] to configure Discrete USB4 Features - PCIe resource, D3 support, Native USB4 support, and so on.

#### Discrete USB4 Support

This item allows you to enable or disable Discrete USB4 PCIe slot.

## DISCRETE USB4 FW Version

Displays the Discrete USB4 firmware version.

## PCIe Bus Number

This item allows you to reserve Discrete USB4 PCIe Bus number per port (16~56).

## PCIe Non-Prefetchable MMIO (MB)

This item allows you to reserve Discrete USB4 PCIe Non-Prefetchable MMIO per port (256~4096 MB).

## PCIe Prefetchable MMIO (MB)

This item allows you to reserve Discrete USB4 PCIe Prefetchable MMIO per port (1~512 GB).

## FWCM Hand off

Discrete USB4 is released or owned by FWCM at OS runtime.

Configuration options: [Released] [Owned]

## ACPI D3 Support

This item allows you enable or disable Discrete USB4 ACPI D3 Support.

Configuration options: [Disabled] [D3Hot] [D3Cold]

## Native USB4

This item allows you enable or disable Discrete USB4 Native USB4 support.

## XHCI Port0 Speed

This item allows you configure the Discrete USB4 XHCI Port0 Speed.

Configuration options: [Gen1x1] [Gen1x2] [Gen2x1] [Gen2x2]

## XHCI Port1 Speed

This item allows you configure the Discrete USB4 XHCI Port0 Speed.

Configuration options: [Gen1x1] [Gen1x2] [Gen2x1] [Gen2x2]

## PCIe SSID SVID Overwrite

Overwrite PCIe Subsystem Device ID and Subsystem Vendor ID, 0 = Keep HW default value.

## USB4/TBT Boot Delay Timing

This item allows you configure the Boot Delay Timing for USB4/TBT Device

(1~20sec) settings.

### USB4 PCIE FPB Support

This item allows you enable or disable USB4 PCIE FPB Support.

### S3 PCIe Save Restore Mode

This item allows you select the S3 PCIe Save Restore Mode.

Mode1: Save at DXE and restore at S3BeforePCI.

Mode2: Save at ACPI\_REG (2, 0) and restore at S3AfterPci.

Configuration options: [Both Disabled] [Mode1] [Mode2] [Both Enabled]

## AMD Common Platform Module

Press [Enter] to configure AMB Common Platform Module options. BIOS procedure library is designed to aid AMD customers to quickly implement AMD platform technology into their products.

### Unused GPP Clocks Off

Allows you to turn Unused GPP Clocks on and off.

### PM L1 SS

Allows you to enable or disable PM L1 SS and ASPM L1 SS.

Configuration options: [Disabled] [L1.1] [L1.2] [L1.1\_L1.2]

### PCIe/GFX Lanes Configuration

Allows you to configure J10 Slot PCIe Lanes.

Configuration options: [Auto] [x8x8] [x8x4x4] [x4x4x4x4]

### PCIe x16 Link Speed

Allows you to configure PCIe X16 Link Speed.

Configuration options: [Auto] [Gen1]-[Gen5]

### M.2\_1 Configuration

Allows you to enable or disable M.2\_1 configuration.

Configuration options: [Enabled] [Disabled]

### M.2\_1 Link Speed

Allows you to configure M.2\_1 Link Speed.

---

Configuration options: [Auto] [Gen1]-[Gen5]

### **Chipset Link Speed**

Allows you to configure Chipset Link Speed.

Configuration options: [Auto] [Gen1]-[Gen4]


### **NVMe RAID mode**

Allows you to enable or disable NVMe RAID mode. Please set the "PCIe/GFX Lanes Configuration" item according to the RAID configuration.

Configuration options: [Disabled] [Enabled]




## 3.4.10 AMD Overclocking



The AMD Overclocking menu accesses options for configuring CPU frequency and voltage.

## 3.5 Tool



### ASR USB LED test form

Press [Enter] configure ASR USB LED test form.

#### LED Mode

Allows you to configure LED Mode.

Configuration options: [Off] [Static] [Breathing] [Strobe] [Cycling] [Wave] [Spring] [Stack] [Cram] [Scan] [Neon] [Water] [Rainbow]

#### Speed

Allows you to configure LED speed, in a range from 0 to 255.

#### Brightness

Allows you to configure LED brightness, in a range from 0 to 255.

#### Apply to all channel

Press [Enter] to apply the settings to all channels.

#### Save current data to MCU

Press [Enter] to save the current data to MCU.

## LED Firmware Recovery

Press [Enter] and a warning message pops up, indicating that "This is a LED firmware recovery process." Press 'Yes' to continue to recover LED Firmware, or press 'No' to abort.

## SSD Secure Erase Tool

Use this tool to securely erase SSD. This tool only lists the SSDs that support the Secure Erase function.

## NVME Sanitization Tool

After you Sanitize SSD, all user data will be permanently destroyed on the SSD and cannot be recovered.

## Instant Flash

Allows you to save UEFI files in your USB storage device and run Instant Flash to update your UEFI.

## Auto Driver Installer


Allows you to download and install all necessary drivers automatically.

[Enabled] Select this item to enable the Auto Driver Installer tool. When it is enabled, after entering to Windows with available Internet access, the Auto Driver Installer tool will appear automatically.

[Disabled] Select this item to disable the Auto Driver Installer tool.

## 3.6 Hardware Health Event Monitoring Screen

This section allows you to monitor the status of the hardware on your system, including the parameters of the CPU temperature, motherboard temperature, fan speed and voltage.



*NOTE: Options vary depending on the features of your motherboard.*

### CPU\_FAN1 Setting

Allows you to select a fan mode for CPU Fan 1, or choose [Customize] to set 5 CPU temperatures and assign a respective fan speed for each temperature.

Configuration options:

[Customize] [Silent Mode] [Standard Mode] [Performance Mode] [Full Speed]

### CPU\_FAN2 Switch

Allows you to switch CPU\_FAN2 / W\_PUMP header function.

Configuration options: [CPU\_FAN2] [W\_PUMP]

### CPU Fan 2 Control Mode

Allows you to select PWM mode or DC mode for CPU Fan 2.

[Auto] Select this mode to detect the type of installed fan and automatically switch the control modes.

[DC Mode] Select this mode for 3-pin fan.

[PWM Mode] Select this mode for 4-pin fan.

## CPU Fan 2 Setting

Allows you to select a fan mode for CPU Fan 2, or choose [Customize] to set 5 CPU temperatures and assign a respective fan speed for each temperature.

Configuration options:

[Customize] [Silent Mode] [Standard Mode] [Performance Mode] [Full Speed]

## CPU Fan 2 Temp Source

Allows you to select a fan temperature source for CPU Fan.

[Monitor M/B] Select this item to set motherboard as the fan temperature source.

[Monitor CPU] Select this item to set CPU as the fan temperature source.

## CHA\_FAN1 Switch

Allows you to switch CHA\_FAN1 / W\_PUMP header function.

Configuration options: [CHA\_FAN1] [W\_PUMP]

## Chassis Fan 1 Control Mode

Allows you to select PWM mode or DC mode for Chassis Fan 1.

[Auto] Select this mode to detect the type of installed fan and automatically switch the control modes.

[DC Mode] Select this mode for 3-pin fan.

[PWM Mode] Select this mode for 4-pin fan.

## Chassis Fan 1 Setting

Allows you to select a fan mode for Chassis Fan 1, or choose [Customize] to set 5 CPU temperatures and assign a respective fan speed for each temperature.

Configuration options:

[Customize] [Silent Mode] [Standard Mode] [Performance Mode] [Full Speed]

## Chassis Fan 1 Temp Source

Allows you to select a fan temperature source for Chassis Fan 1.

[Monitor M/B] Select this item to set motherboard as the fan temperature source.

[Monitor CPU] Select this item to set CPU as the fan temperature source.

## CHA\_FAN2 Switch

Allows you to switch CHA\_FAN2 / W\_PUMP header function.

Configuration options: [CHA\_FAN2] [W\_PUMP]

## Chassis Fan 2 Control Mode

Allows you to select PWM mode or DC mode for Chassis Fan 2.

[Auto] Select this mode to detect the type of installed fan and automatically switch the control modes.

[DC Mode] Select this mode for 3-pin fan.

[PWM Mode] Select this mode for 4-pin fan.

## Chassis Fan 2 Setting

Allows you to select a fan mode for Chassis Fan 2, or choose [Customize] to set 5 CPU temperatures and assign a respective fan speed for each temperature.

Configuration options:

[Customize] [Silent Mode] [Standard Mode] [Performance Mode] [Full Speed]

## Chassis Fan 2 Temp Source

Allows you to select a fan temperature source for Chassis Fan 2.

[Monitor M/B] Select this item to set motherboard as the fan temperature source.

[Monitor CPU] Select this item to set CPU as the fan temperature source.

## CHA\_FAN3 Switch

Allows you to switch CHA\_FAN3 / W\_PUMP header function.

Configuration options: [CHA\_FAN3] [W\_PUMP]

## Chassis Fan 3 Control Mode

Allows you to select PWM mode or DC mode for Chassis Fan 3.

[Auto] Select this mode to detect the type of installed fan and automatically switch the control modes.

[DC Mode] Select this mode for 3-pin fan.

[PWM Mode] Select this mode for 4-pin fan.

## Chassis Fan 3 Setting

Allows you to select a fan mode for Chassis Fan 3, or choose [Customize] to set 5 CPU temperatures and assign a respective fan speed for each temperature.

Configuration options:

[Customize] [Silent Mode] [Standard Mode] [Performance Mode] [Full Speed]

## Chassis Fan 3 Temp Source

Allows you to select a fan temperature source for Chassis Fan 3.

[Monitor M/B] Select this item to set motherboard as the fan temperature source.

[Monitor CPU] Select this item to set CPU as the fan temperature source.

## AIO\_PUMP Control Mode

Allows you to select PWM mode or DC mode for AIO\_PUMP.

[Auto] Select this mode to detect the type of installed fan and automatically switch the control modes.

[DC Mode] Select this mode for 3-pin fan.

[PWM Mode] Select this mode for 4-pin fan.

## AIO\_PUMP Setting

Allows you to select a fan mode for Fan, or choose [Customize] to set 5 CPU temperatures and assign a respective fan speed for each temperature.

Configuration options:

[Customize] [Silent Mode] [Standard Mode] [Performance Mode] [Full Speed]

## Fan-Tastic

Allows you to select a fan mode for Fan, or choose [Customize] to set 5 CPU temperatures and assign a respective fan speed for each temperature.

## FanTuning

When selected, the BIOS will proceed to detect the lowest fan speeds for fans connected to the motherboard. This process will take a few minutes to complete.

Note: Please note CAM settings applied within the OS will overwrite settings made within the BIOS.

Select a fan mode or customize the profile

The image shows the ASRock UEFI Fan-tastic interface. At the top, there are four fan mode options: Silent, Standard, Performance, and Full Speed. Below these are two temperature source options: Monitor CPU and Monitor M/B. A central graph plots fan speed (%) on the y-axis (0 to 100) against temperature (°C) on the x-axis (0 to 100). The graph shows a curve that starts at approximately 30% fan speed at 25°C and rises to 100% at 75°C. On the left side, there is a list of fan settings: All Fans Setting, CPU Fan 1, CPU Fan 2, Chassis Fan 1, Chassis Fan 2, Chassis Fan 3, and AIO\_PUMP. At the bottom right, there are three buttons: Discard, Apply, and Exit. The interface also shows 'Easy Mode (F6)' in the top right corner and system information at the bottom: English and Mon 01/01/2024, 06:01:51.

Select Fan(s) to adjust


Select a fan temperature source

Save the setting



## 3.7 Security Screen

In this section you may set or change the supervisor/user password for the system. You may also clear the user password.



### Supervisor Password

Set or change the password for the administrator account. Only the administrator has authority to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

### User Password

Set or change the password for the user account. Users are unable to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

### Secure Boot

Press [Enter] to configure the Secure Boot Settings. The feature protects the system from unauthorized access and malwares during POST.

#### Secure Boot Mode

[Standard] Select this item and the system will automatically load the Secure Boot keys from the BIOS database.

[Custom] Select this item and Secure Boot Policy variables can be configured by a physically present user without full authentication.

## Install Default Secure Boot Keys

Please install default secure boot keys if it's the first time you use secure boot.

## Clear Secure Boot Keys

This item appears only when you load the default Secure Boot keys. Use this item to clear all default Secure Boot keys.

## Key Management

This item enables expert users to modify Secure Boot Policy variables without full authentication. This appears only when you set Secure Boot Mode to [Custom].

## Factory Key Provision

Allows you to install factory default Secure Boot keys after the platform reset and while the System is in Setup mode.

## Install Default Secure Boot Keys

Please install default secure boot keys if it's the first time you use secure boot.

## Clear Secure Boot Keys

This item appears only when you load the default Secure Boot keys. Use this item to clear all default Secure Boot keys.

## Export Secure Boot variables

Allows you to copy NVRAM content of Secure Boot variables to files in a root folder on a file\_system device.

## Enroll Efi Image

Allows the image to run in Secure Boot mode. Enroll SHA256 hash of the binary into Authorized Signature Database (db).

## Device Guard Ready

### Remove 'UEFI CA' from DB

Device Guard ready system must not list 'Microsoft UEFI CA' Certificate in Authorized Signature database (db).

## Restore DB defaults

Allows you to restore DB variable to factory defaults.

## Platform Key(PK)

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:

- a) EFI\_SIGNATURE\_LIST
- b) EFI\_CERT\_X509 (DER)
- c) EFI\_CERT\_RSA2048 (bin)
- d) EFI\_CERT\_SHAXXX

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

## Key Exchange Keys

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:

- a) EFI\_SIGNATURE\_LIST
- b) EFI\_CERT\_X509 (DER)
- c) EFI\_CERT\_RSA2048 (bin)
- d) EFI\_CERT\_SHAXXX

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

## Authorized Signatures

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:

- a) EFI\_SIGNATURE\_LIST
- b) EFI\_CERT\_X509 (DER)
- c) EFI\_CERT\_RSA2048 (bin)
- d) EFI\_CERT\_SHAXXX

2. Authenticated UEFI Variable

3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

## Forbidden Signatures

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:
  - a) EFI\_SIGNATURE\_LIST
  - b) EFI\_CERT\_X509 (DER)
  - c) EFI\_CERT\_RSA2048 (bin)
  - d) EFI\_CERT\_SHAXXX
2. Authenticated UEFI Variable
3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

## Authorized TimeStamps

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:
  - a) EFI\_SIGNATURE\_LIST
  - b) EFI\_CERT\_X509 (DER)
  - c) EFI\_CERT\_RSA2048 (bin)
  - d) EFI\_CERT\_SHAXXX
2. Authenticated UEFI Variable
3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

## OsRecovery Signatures

Enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:
  - a) EFI\_SIGNATURE\_LIST
  - b) EFI\_CERT\_X509 (DER)
  - c) EFI\_CERT\_RSA2048 (bin)
  - d) EFI\_CERT\_SHAXXX
2. Authenticated UEFI Variable
3. EFI PE/COFF Image(SHA256)

Key Source: Factory, External, Mixed

## 3.8 Boot Screen

This section displays the available devices on your system for you to configure the boot settings and the boot priority.



### Boot Option #1

Use this item to set the system boot order.

### CSM

CSM (Compatibility Support Module) is enabled for better compatibility for the non-UEFI driver add-on devices. If you are using UEFI aware OS and all of your devices support UEFI, you may also disable CSM for faster boot speed.

Configuration options: [Disabled] [Enabled]

### Launch PXE OpROM Policy

[UEFI only] Select this item to run those that support UEFI option ROM only.

[Do not launch] Select this item to not execute both legacy and UEFI option ROM.

### Launch Storage OpROM Policy

[UEFI only] Select this item to run those that support UEFI option ROM only.

[Do not launch] Select this item to not execute both legacy and UEFI option ROM.

### Setup Prompt Timeout

Allows you to configure the number of seconds to wait for the setup hot key.

## Bootup Num-Lock

Allows you to select whether Num Lock should be turned on or off when the system boots up.

## Full Screen Logo

[Enabled] Select this item to display the boot logo.


[Disabled] Select this item to show normal POST messages.

## Fast Boot

Fast Boot speeds up your computer's boot time; however you won't be able to boot from an USB storage device. Ultra Fast mode is supported by UEFI aware OS or later versions, and a VBIOS that supports UEFI GOP is required if you are using an external graphics card. Please note that Ultra Fast mode boots so fast that the only way to enter this UEFI Setup Utility is to clear CMOS or run the Restart to UEFI utility in Windows.

Configuration options: [Disabled] [Ultra Fast]

## 3.9 Exit Screen



### Save Changes and Exit

When you select this option the following message, “Save configuration changes and exit setup?” will pop out. Press <F10> key or select [Yes] to save the changes and exit the UEFI SETUP UTILITY.

### Discard Changes and Exit

When you select this option the following message, “Discard changes and exit setup?” will pop out. Press <ESC> key or select [Yes] to exit the UEFI SETUP UTILITY without saving any changes.

### Discard Changes

When you select this option the following message, “Discard changes?” will pop out. Press <F7> key or select [Yes] to discard all changes.

### Load UEFI BIOS Defaults

Allows you to load UEFI default values for all options. The F9 key can be used for this operation.

### Launch EFI Shell from filesystem device

Allows you to copy shellx64.efi to the root directory to launch EFI Shell.