

Quick Start Guide

ENGLISH | DEUTSCH | ESPAÑOL | FRANÇAIS | ITALIANO
РУССКИЙ | УКРАЇНСЬКА | 繁體中文

Contents

Connecting the PoE Injector

LEDs


Troubleshooting

Wall Mounting (Optional)

Certifications

Support Information

Connecting the PoE Injector



- EN
- 1

Connect an Ethernet device to the **IN** port of the PoE injector.
- 2

Connect a Powered Device (PD) to the **OUT** port of the PoE injector.
- 3

Use the included power cord to connect the PoE Injector's power socket to a power source (wall outlet or power strip).
- DE
- 1

Verbinden Sie den **IN** Port des PoE-Injector mit einem Ethernetkabel mit Ihrem Netzwerk.
- 2

Verbinden Sie ihr PoE-Gerät mit dem Ethernetkabel mit dem **OUT** Port des PoE-Injector.
- 3

Schließen Sie das mitgelieferte Stromkabel an den Netzanschluss und an das Stromnetz an (Wandsteckdose oder Steckdosenleiste).
- ES
- 1

Conecte el dispositivo Ethernet al puerto **IN** de inyector PoE.
- 2

Conecte el dispositivo que necesita ser alimentado vía PoE al puerto **OUT** del inyector PoE.
- 3

Utilice el cable de corriente incluido para conectar el enchufe eléctrico a la fuente de alimentación (toma de corriente o regleta).
- FR
- 1

Connectez le peripherique Ethernet au port **IN** de l'injecteur PoE.
- 2

Connectez le peripherique PoE au port **OUT** de l'injecteur PoE.
- 3

Utilisez le cordon d'alimentation fourni pour connecter la prise d'alimentation à une source d'alimentation (prise murale ou une prise multiple).
- IT
- 1

Collegare il dispositivo Ethernet alla porta **IN** dell'iniettore PoE.
- 2

Collegare il dispositivo abilitato PoE alla porta **OUT** dell'iniettore PoE.
- 3

Utilizzare il cavo di alimentazione in dotazione per collegare la presa di alimentazione ad una sorgente di alimentazione (presa a muro o ciabatta elettrica).
- RU
- 1

Подключите устройство Ethernet к порту **IN** инжектора PoE.
- 2

Подключите устройство с поддержкой PoE к порту **OUT** инжектора PoE.
- 3

Используйте прилагаемый в комплекте кабель питания для подключения разъема питания PoE-инжектора к электросети.
- UA
- 1

Підключіть пристрій Ethernet до порту **IN** інжектора PoE.
- 2

Підключіть пристрій з підтримкою PoE до порту **OUT** інжектора PoE.
- 3

Скористайтесь в комплекті кабель живлення для підключення роз'єму живлення PoE-інжектора до електромережі.
- 繁中
- 1

使用乙太網路線PoE Injector的 **IN**埠連結至乙太網路裝置的LAN (例如乙太網路交換器)。
- 2

OUT埠將電力和乙太網路傳送到PoE裝置。使用一對一乙太網路線將**OUT**埠連接到PoE裝置。
- 3

使用隨附的電源線將電源插槽連接到電源 (牆面插座或插座組)。

Certifications

Federal Communications Commission (FCC) Interference Statement

The device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operations.

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio/television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

CE Mark Warning:

This is a class B product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Viewing Certifications

Go to <http://www.zyxel.com>.

Select your product on the Zyxel home page to go to that product's page.
Select the certification you wish to view from this page.

Support Information

USA

+ 1 800 255 4101
support@zyxel.com

EU

https://support.zyxel.eu

Taiwan

+ 886 2 2739 9889
retail@zyxel.com.tw

Zyxel Community

https://community.zyxel.com

EU Importer
Zyxel Networks A/S
Gldsaxevej 378, 2. th. 2860 Søborg, Denmark
<https://www.zyxel.com/dk/da/>

UK Importer
Zyxel Networks UK
2 Old Row Court, Rose Street, Wokingham, RG40 1XZ, United Kingdom
<https://www.zyxel.com/uk/en/>

US Importer
Zyxel Communications, Inc.
1130 North Miller Street Anaheim, CA 92806-2001
<https://www.zyxel.com/us/en/>