

AMAZWATCH Numix

MULTIFUNCTIONAL SMART WATCH

User Manual

Device Maintenance

Please follow the tips below while using the smartwatch:

Do not forget to clean the smartwatch, especially the inner side; keep it dry.

Adjust the tightness of the smartwatch on your wrist to ensure proper air circulation.

Avoid applying excessive creams, sanitizers, and other skincare products on your wrist before using the smartwatch.

Stop wearing the smartwatch if you experience any allergic reactions or discomfort.

Package Contents:

- Smartwatch
- Wireless USB charging device
- User manual

Incorrect placement of the wireless charger may result in reduced charging efficiency.

Before using the watch for the first time, it must be charged and activated. Use the magnetic charging cable to attach it to the metal charging area on the back of the watch. The other end of the charging cable should be connected to the USB port of the charger.


Precautions:

Please use the charging cable included in the package and ensure that the charging contacts are dry and free of any dirt or debris that may obstruct the charging process before charging the device.

Connect the charging cable to a standard charger or USB port obtained through official representatives that has received quality compliance certification and meets standard requirements.

If the watch does not turn on after being left unused for an extended period, it should be charged for approximately 2-3 minutes before use until the charging complete. Otherwise, please contact an official service center or the place of purchase for assistance.

Activation and Charging of the Watch



Activation and Charging of the Watch

Before using the watch for the first time, it must be charged and activated. Use the magnetic charging cable to attach it to the metal charging area on the back of the watch. The other end of the charging cable should be connected to the USB port of the charger.

Precautions:

Please use the charging cable included in the package and ensure that the charging contacts are dry and free of any dirt or debris that may obstruct the charging process before charging the device.

Connect the charging cable to a standard charger or USB port obtained through official representatives that has received quality compliance certification and meets standard requirements.

If the watch does not turn on after being left unused for an extended period, it should be charged for approximately 2-3 minutes before use until the charging complete. Otherwise, please contact an official service center or the place of purchase for assistance.

Download and Pairing

1 Press and hold the upper "POWER" button to turn on the device.

2 Scan the QR code provided below to install the free "Da Fit" app, or download "Da Fit" from the App Store or Google Play, and then install it.

Compatible system: Android 4.4 and above, iOS 8.0 and above.

3 Open the "Da Fit" mobile app, select the device to be paired from the list of devices (GP-SW009).

4 Turn on Bluetooth on your mobile phone and open the "Da Fit" app; then tap "Add device" to connect.

5 Enable the phone to the watch's Bluetooth menu and connect to the device listed (GP-SW009).

6 After the watch is successfully paired with the phone, each time the app is launched, the watch will automatically connect to the phone, and data can be synchronized by opening the "Da Fit" app.

Activation and Charging of the Watch

Before using the watch for the first time, it must be charged and activated. Use the magnetic charging cable to attach it to the metal charging area on the back of the watch. The other end of the charging cable should be connected to the USB port of the charger.

Precautions:

Please use the charging cable included in the package and ensure that the charging contacts are dry and free of any dirt or debris that may obstruct the charging process before charging the device.

Connect the charging cable to a standard charger or USB port obtained through official representatives that has received quality compliance certification and meets standard requirements.

If the watch does not turn on after being left unused for an extended period, it should be charged for approximately 2-3 minutes before use until the charging complete. Otherwise, please contact an official service center or the place of purchase for assistance.

Call Function

You have not link a device.

Recent Call

Dial Pad

Contacts

Phone Call

Exercise

Exercise Records

Blood Pressure

Spo2

Stress

Heart Rate

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09

10:09


10:09

10:09

10:09

10:09

10:09</p



Список меню функції

Проведіть вправо: Сповіщення

Проведіть вліво: Інтерфейс основних функцій

Тривале натискання: Перемикання циферблату

Верхня кнопка:

Коротке натискання: Увімкнення екрану/Перехід в меню.

Тривале натискання: Тривале натискання протягом 3 секунд для відображення інтерфейсу перемикання циферблата.

Подвійне натискання: Перехід до нещодавно використаних функцій.

Обертання: Перемикання циферблата або прокручування списків меню.

Нижня кнопка:

Увімкнення: Тривале натискання протягом 3 секунд, доки не засвітиться екран.

Вимкнення: Тривале натискання протягом 3 секунд, виберіть [Вимкнути живлення]. Гаряча клавіша: Налаштування функцій кнопки в додатку.

що пристрій не вмикається після натискання та утримання кнопки вимкнення протягом 3 секунд, підключіть його до зарядки та спробуйте заново.

- Heart Rate
- Phone Call
-  Exercise
-  Exercise Records
-  Blood Pressure
-  SpO2
- Shutter
- Player
-  Relaxation
-  Timer
-  Alarm
-  Stopwatch
- Find Phone
- Calculator
-  AI Voice
-  Games
-  Muslim
-  Stock

- The image shows a vertical guide for the smartwatch's interface. At the top, there are three circular icons representing different apps: SpO2 (blue), Stress (orange), and Stopwatch (blue). Below these are sections for 'Список функцій' (List of functions) and 'Функції інтерфейсу смарт-годинника' (Smartwatch interface functions). The 'List of functions' section lists various features like Activity, Sleep, Weather, and Settings. The 'Smartwatch interface functions' section includes: 1) A large circular icon showing the main screen with time (10:09), date (Sep 28 WED), and battery level (100%). It also shows a smaller circular icon with a play button and a progress bar. 2) A section titled 'Перемикач циферблатів' (Switch for watch faces) with instructions on how to switch between faces by holding a button. 3) A section titled 'Панель управління' (Control panel) showing a grid of icons for Sleep, Activity, Weather, and Settings. 4) A section titled 'Дані активності' (Activity data) showing a play button icon and a summary of steps taken (6028) and calories burned (368 Kcal). 5) A section titled 'Фізичні вправи' (Physical exercises) showing a list of activities: Walking, Running, Cycling, and Skipping, each with a plus sign to start. 6) A section titled 'Записи вправ' (Exercise logs) showing a summary of exercise data: Total Steps (6028), Total Calories (368 Kcal), and a timestamp (00:34:05). 7) A section titled 'Сон' (Sleep) showing sleep duration (07 Hour 26 Min) and a breakdown of sleep stages: Asleep (22:56 PM - 06:22 AM) and Awake (06:22 AM - 10:09 AM). 8) A section titled 'Частота серцебиття' (Heart rate) showing the current heart rate (128 BPM) and a range from 58 to 168 BPM.

The image shows a black smartwatch with a circular face. At the top left, it displays "Blood Pres..." and "10:09". The main area shows a blood pressure reading of "125 / 86 mmHg". Below this, "SBP" and "DBP" are listed with values "130" and "60-86" respectively. A small orange icon of a heart with a pulse line is on the left. On the right side of the watch face, there is a large, bold text "Arterialnyi tisk" followed by descriptive text about the measurement process.

Arterialnyi tisk

Коли ви входите в інтерфейс вимірювання артеріального тиску, зелене світло внизу загоряється, щоб розпочати вимірювання. Вимірювання завершується протягом 30–60 секунд. Це вимірювання базується на технології PPG.



Функції інтерфейсу смарт-годинник

- The image shows a smartwatch interface with several cards displayed:

 - World Clock**: Shows the time as 10:09 AM. Below it, there's a sun icon and the text "Day, +0HRS".
 - Find Phone**: Shows a target icon and the text "Find Phone".
 - Games**: Shows the word "Hamster" and the number "2048".

On the right side of the screen, there are explanatory text blocks corresponding to each card:

 - Світовий час**
Ви можете переглядати час, який ви налаштували для інших міст у додатку.
 - Знайти телефон**
Після натискання на екран ви зможете знайти мобільний телефон, підключений до цих годинників.
 - Ігри**
На годиннику є кілька головоломок.

* Потрібно підключити додаток, перш ніж ви зможете його використовувати.

A digital calculator interface is shown on the left side of the screen. The display shows '0' at the top. Below it is a numeric keypad with digits 8, 9, 5, 6, 2, 3, and a decimal point. To the right of the keypad are four blue operation buttons: division, multiplication, subtraction, and addition. At the bottom right is an equals sign button. The background of the calculator area is black.



Оширені проблеми та їх вирішення



Всім пристроям, які проходять випробування на проникнення частинок вологої і впливу пилу присвоюється певний ступінь захисту. Він складається з самої абревіатури IP та двох символів після неї. Перша цифра із двох (IPXX) визначає ступінь захисту від проникнення твердих частинок. Друга цифра в позначенні ступеня захисту (IPXX) означає рівень захисту від попадання води. У деяких випадках одна з цифр може замінюватися на X. Якщо вказаний клас захисту IPX7, то він витримає попадання струменів води, а на захист від пилу він

