



HYPE-M


MODERN AESTHETIC CASE

USER MANUAL BENUTZERHANDBUCH MANUAL DO USUÁRIO РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ 用户手册


Package Content - Paket Inhalt - Conteúdo do pacote - Содержание пакета - 包装内容


	Image	Q'ty	Used for / Benutzt für / Usado para / Используется для / 用途
A		10	Screws - MB+2.5\" SSD / Schrauben - MB+2.5\" SSD / Parafusos - MB+2.5\" SSD / Винты - MB+2.5\" SSD / 主板+2.5\" SSD硬盘螺丝
B		5	Power Supply Screw / Stromversorgungsschraube / Parafuso de fonte de alimentação / Винт питания / 电源螺丝
C		4	Screws - 3.5\" HDD / Schrauben - 3.5\" HDD / Parafusos - 3.5\" HDD / Винты - 3.5\" HDD / 3.5\" HDD硬盘螺丝
D		3	Spare MB Stand-off / Ersatz MB-Abstand / Suporte de MB sobressalente / Запасной блок MB / 备用主板铜柱
E		5	Cable Tie / Kabelbinder / Abraçãoeira / Кабельная стяжка / 束线带

Connectors - Anschlüsse - Conectores - Разъемы - 连接器

PORT 1L  AUG GND PORT 1R  PRESENCE PORT 2R  SENSE1_R SENCE_S  SENSE2_R PORT 2L  SENSE2_R 	Combo Audio	 POWER SW	POWER SW
USB+5V  USB+5V LP  LP LPH  LPH GND  GND NC  NO PIN 	USB2.0	 RESET SW	RESET SW
VBUS  VBUS SSRX1+  SSRX2+ GND  GND SSTX1+  SSTX2+ GND  GND D1+  D2+ D1-  D2- NC  NO PIN 	USB3.0	 LED SW	LED SW


I/O Panel - N/O Panel - Painei de N/O - Панель N/O - I/O面板

	 LED SW  Reset SW  Power / HDD LED  Combo Audio  USB2.0  USB2.0  USB3.0  Power SW
---	---



①	Tempered glass front panel / Temperatur front platte / Painei frontal de vidro temperado / Передняя панель с закаленным стеклом / 钢化玻璃面板	⑦	Rear fan x1(included) / Heck -Lüfter x1(enthalten) / Ventilador traseiro x1(incluido) / Задний вентилятор x1(включен) / 后板风扇 x1(标配)
②	Tempered glass left side panel / Linker Schaltplatte mit geschmiedeten Glas / Painei lateral esquerdo de vidro temperado / Панель левой боковой панели / 钢化玻璃左侧板	⑧	Top fan x3(optional) / Oberer Lüfter x3(enthalten) / Ventilador inferior x3(opcional) / Верхний вентилятор x3 (опционально) / 顶部风扇 x3(选配)
③	Right side panel / Rechte Seite / Painei lateral direito / Правая панель / 右侧板	⑨	Bottom fan x3(optional) / Unterer Lüfter x3 (optional) / Ventilador traseiro x1(incluido) / Нижний вентилятор x3 (опционально) / 底板风扇 x3(选配)
④	Chassis / Chassis / Chassis / Шасси / 机架	⑩	Magnetic dust filter on top / Magnetstaubfilter oben / Filtro de poeira magnética por cima / Магнитный пыли фильтр сверху / 顶板磁吸式防尘网
⑤	HDD bracket / HDD -Klammer / Bracket de HDD / HDD кронштейн / HDD硬盘架	⑪	Magnetic dust filter at the bottom / Ausziehbarer Staubfilter an der Unterseite / Filtro de poeira removível na parte inferior / Выдвижной пылевой фильтр в нижней части / 底部抽拉式防尘网
⑥	Motherboard plate fan x2(included) / Motherboard Plattenlüfter x2(enthalten) / Fã da placa -mãe x2(incluido) / Материнская пластина вентилятор x2(включен) / 主板位风扇 x2(标配)	⑫	PWM ARGB HUB / PWM ARGB HUB / HUB ARGB PWM / PWM ARGB HUB / 风扇控制器

Installation Guide - Installationsanleitung - Guia de instalação - Инструкция по установке - 安装指南



Remove the side panels.


Entfernen Sie die Seitenpaneele.

Remova os painéis laterais.

Снимите боковые панели.

取下左右侧板。

Installation Guide - Installationsanleitung - Guia de instalação - Инструкция по установке - 安装指南



Insert PSU from right side, secure with screws.


Setzen Sie PSU von der rechten Seite ein und sicher mit Schrauben.

Insira a PSU do lado direito, prenda com parafusos.


Вставьте PSU с правой стороны, закрепите винтами.


将电源从右侧置入，对齐孔位，锁上电源螺丝。

Installation Guide - Installationsanleitung - Guia de instalação - Инструкция по установке - 安装指南

	Put in the motherboard, place the I/O baffle, and lock the screws.
	Setzen Sie die Hauptplatine ein, bringen Sie die E/A-Abdeckung an und ziehen Sie die Schrauben fest.
	Coloque a placa-mãe, posicione o defletor de E/S e trave os parafusos.
	Установите материнскую плату, установите перегородку ввода-вывода и закрепите винты.
	將主板放在對應位置，置入I/O擋板，用主板螺絲固定。

Installation Guide - Installationsanleitung - Guia de instalação - Инструкция по установке - 安装指南

	Remove the PCI-E slot strip and install graphics card.
	Entfernen Sie den PCI-E-Spielstreifen und installieren Sie die Grafikkarte.
	Remova a tira do slot PCI-E e instale a placa gráfica
	Снимите полосу слота PCI-E и установите видеокарту.
	拆下PCI-E介面卡条，安装GPU显卡。




Remove the hard disk cage.

Entfernen Sie den Festplattenkäfig.

Remova o compartimento do disco rígido.

Снимите обойму жесткого диска.

取下硬盘架。




Install 2.5" SSD.

Installieren Sie 2.5" SSD.

Instale o SSD de 2.5".

Установите 2.5" SSD.

安装2.5" SSD硬盘。




Install 3.5" HDD.

Installieren Sie 3.5" HDD.

Instale o HDD de 3.5".

Установите 3.5" HDD.

安裝HDD硬盤。



Install the hard disk cage.


Installieren Sie den Festplattenkäfig.

Instale o compartimento do disco rígido.

Установите клетку для жесткого диска.

安裝硬盤架。

Cooling System - Installationsanleitung - Guia de instalação - Инструкция по установке - 散热支持



Fan Cooling System:

Top: 3x120mm, 2x140mm(optional)

M/B Cover: 2x120mm(included)

Bottom: 3x120mm / 2x140mm(optional)

Rear: 1x120mm(included)

Liquid Cooling System:

Top: 120/240/360mm(optional)

M/B Cover: 240mm(optional)

PWM ARGB HUB - PWM ARGB HUB - PWM ARGB HUB - ШИМ Apr6 Ха6 - PWM ARGB控制器

PWM ARGB HUB DEMO LINK GUIDE




Please do not plug in the wrong power interface, otherwise it will burn out equipment!

Link LED SW or REST Button,
Manual ARGB Control



SATA Power input



5V 3pin AURA Cable

ARGB

PWM TEMP Cable
Link to CPU Fan socket



CPU Cooler Fan
Link 1st PWM Port(Red)

